



SUTPHEN CORPORATION MODEL SPI 95 AERIAL PLATFORM OPERATOR AND MAINTENANCE MANUAL



SUTPHEN

IMPORTANT

READ AND UNDERSTAND THIS MANUAL BEFORE OPERATING

FAILURE TO USE, UNDERSTAND, AND FOLLOW PROPER USAGE INSTRUCTIONS AS MADE AVAILABLE BY SUTPHEN CORPORATION/OPERATOR'S MANUAL, VARIOUS VENDOR SUPPLIED LITERATURE, GUIDELINES OF N.F.P.A., I.S.F.S.I., O.S.H.A., ETC., COULD CAUSE SERIOUS INJURY AND/OR DEATH.

**SUTPHEN
Since 1890**

Rev. 2 - May 2024



Chapter 1 Operator Manual

| | <i>Page</i> |
|--|--------------------|
| 1.1 Introduction | 1-3 |
| 1.2 Aerial Platform Operation..... | 1-4 |
| <i>Operation Safety Points</i> | 1-4 |
| 1.3 Safety Tags..... | 1-8 |
| <i>Warning/Danger/Caution Labels List</i> | 1-25 |
| <i>Safety Tags Location</i> | 1-27 |
| <i>Rear/Bucket Warning Tags</i> | 1-28 |
| <i>Rear/Bucket warning Tags List</i> | 1-31 |
| 1.4 Cab Setup Procedures | 1-32 |
| <i>Locating the Vehicle</i> | 1-32 |
| <i>Activating the Hydraulic System</i> | 1-32 |
| 1.5 Cab Setup for Fire Pump Operation..... | 1-33 |
| 1.6 Aerial Setup Procedures..... | 1-35 |
| 1.7 Stabilizing System..... | 1-35 |
| 1.8 Safety Pins..... | 1-40 |
| 1.9 Transfer Fluid for Aerial Operation | 1-42 |
| 1.10 Stabilizer Interlock System | 1-43 |
| <i>Stabilizer Interlock Override Procedure</i> | 1-43 |
| 1.11 Rotation Interlock System..... | 1-44 |
| 1.12 Smart Boom Warning System..... | 1-45 |



| | <u>Page</u> |
|--|-------------|
| 1.13 Aerial Operational Controls | 1-46 |
| <i>Raise/Lower</i> | 1-47 |
| <i>Extend/Retract</i> | 1-48 |
| <i>Rotation</i> | 1-48 |
| <i>High-Speed Control</i> | 1-48 |
| <i>Auxiliary Hydraulic Power Switch</i> | 1-50 |
| 1.14 Water Delivery System | 1-50 |
| <i>Telescopic Waterway</i> | 1-50 |
| <i>Platform Water System</i> | 1-51 |
| 1.15 Cold Weather Operations | 1-52 |
| <i>Draining the Waterway</i> | 1-52 |
| 1.16 Draining the Fire Pump | 1-52 |
| 1.17 Platform Mounting and Leveling System | 1-53 |
| <i>Leveling System Override</i> | 1-53 |
| 1.18 Optional Breathing Air System..... | 1-54 |
| 1.19 Climbing Aerial or Using as an Escapeway..... | 1-55 |
| 1.20 Rappelling | 1-55 |
| 1.21 Loading Hose | 1-55 |
| 1.22 Aerial Take Down Procedures | 1-56 |
| <i>Stowing the Aerial Device</i> | 1-56 |



Chapter 2 Maintenance Manual

| | <u>Page</u> |
|--|-------------|
| 2.1 Aerial Maintenance | 2-3 |
| <i>Outrigger Beams</i> | 2-3 |
| <i>Main Lift Cylinders</i> | 2-3 |
| <i>Pivot Shaft Bearings</i> | 2-3 |
| <i>Turntable Bearing</i> | 2-3 |
| <i>Fairfield Drive</i> | 2-4 |
| <i>Aerial Extension/Retraction Cylinders</i> | 2-5 |
| 2.2 Cable Adjustment..... | 2-6 |
| <i>Cable Lubrication</i> | 2-17 |
| <i>Sheaves and Cables</i> | 2-17 |
| <i>Slide Block</i> | 2-19 |
| Lubrication | 2-19 |
| Description | 2-19 |
| Daily Preventative Maintenance (PM) | 2-20 |
| Before Beginning | 2-20 |
| Standard Operating Procedure | 2-21 |
| Periodic Preventative Maintenance (PM) | 2-23 |
| <i>Cable Track</i> | 2-24 |
| Maintenance | 2-24 |
| <i>Waterway and Seals</i> | 2-26 |
| <i>Hydraulic Oil Tank</i> | 2-27 |

Hydraulic Oil Tank Fill Procedure..... 2-28

SPI 95 Fitted with

KFS 4573 Hydraulic Reservoir..... 2-29

Fuel Tank 2-31

2.3 Maintenance of Structure 2-31

Aluminum Tower Structure 2-31

2.4 Sutphen-Recommended Torque Schedule

for Various Fasteners 2-32

2.5 Daily/Weekly Walk-Around Check for Mobile Fire Apparatus 2-35

2.6 Draining & Winterizing Trucks 2-39

Chapter 3

Warranty

Aerial Platform or Aerial Ladder Structural and Corrosion Warranty

Thirty (30) Years..... 3-3

Aerial Platform and Aerial Ladder Mechanical Warranty


Two (2) Years 3-4



Chapter 1

Operator Manual

| | <u>Page</u> |
|--|-------------|
| 1.1 Introduction | 1-3 |
| 1.2 Aerial Platform Operation | 1-4 |
| <i>Operation Safety Points</i> | 1-4 |
| 1.3 Safety Tags | 1-8 |
| <i>Warning/Danger/Caution Labels List</i> | 1-25 |
| <i>Safety Tags Location</i> | 1-27 |
| <i>Rear/Bucket Warning Tags</i> | 1-28 |
| <i>Rear/Bucket warning Tags List</i> | 1-31 |
| 1.4 Cab Setup Procedures | 1-32 |
| <i>Locating the Vehicle</i> | 1-32 |
| <i>Activating the Hydraulic System</i> | 1-32 |
| 1.5 Cab Setup for Fire Pump Operation | 1-33 |
| 1.6 Aerial Setup Procedures | 1-35 |
| 1.7 Stabilizing System | 1-35 |
| 1.8 Safety Pins | 1-40 |
| 1.9 Transfer Fluid for Aerial Operation | 1-42 |
| 1.10 Stabilizer Interlock System | 1-43 |
| <i>Stabilizer Interlock Override Procedure</i> | 1-43 |
| 1.11 Rotation Interlock System | 1-44 |
| 1.12 Smart Boom Warning System | 1-45 |

 **Operator Manual**

| | <u>Page</u> |
|--|-------------|
| 1.13 Aerial Operational Controls | 1-46 |
| <i>Raise/Lower</i> | 1-47 |
| <i>Extend/Retract</i> | 1-48 |
| <i>Rotation</i> | 1-48 |
| <i>High-Speed Control</i> | 1-48 |
| <i>Auxiliary Hydraulic Power Switch</i> | 1-50 |
| 1.14 Water Delivery System | 1-50 |
| <i>Telescopic Waterway</i> | 1-50 |
| <i>Platform Water System</i> | 1-51 |
| 1.15 Cold Weather Operations | 1-52 |
| <i>Draining the Waterway</i> | 1-52 |
| 1.16 Draining the Fire Pump | 1-52 |
| 1.17 Platform Mounting and Leveling System | 1-53 |
| <i>Leveling System Override</i> | 1-53 |
| 1.18 Optional Breathing Air System | 1-54 |
| 1.19 Climbing Aerial or Using as an Escapeway..... | 1-55 |
| 1.20 Rappelling | 1-55 |
| 1.21 Loading Hose | 1-55 |
| 1.22 Aerial Take Down Procedures | 1-56 |
| <i>Stowing the Aerial Device</i> | 1-56 |



1.1 Introduction

This manual has been prepared with the assistance of service and engineering specialists to acquaint you with the operation and maintenance of your new apparatus. You are urged to read this manual carefully. Following the instructions and recommendations in this manual will help ensure the safe and enjoyable operation of your apparatus.

After you have read this manual, it should be stored in the apparatus or another location which enables quick and easy reference for all firefighters.

Throughout this manual, the words WARNING, DANGER, and CAUTION appear. These serve as reminders to follow all instructions carefully. Failure to follow instructions can cause personal injury or damage to your apparatus.

This manual has been written to help in the setup and use of the tower during emergencies.

There may be circumstances that arise throughout the life of this apparatus which do not appear in this manual. At all times, common sense and safety should be your first consideration.

Sutphen knows your apparatus best and has the parts and factory-trained technicians available to keep your apparatus in an ever-ready state. Sutphen Corporation works towards giving you complete satisfaction. Please do not hesitate to contact Sutphen Corporation at 866-287-5549.

1.2 Aerial Platform Operation

Operation Safety Points

When the truck is delivered, a factory-trained representative will demonstrate the proper use of the apparatus. The department must continue this to achieve a proficient level of training.

The aerial tower is only as good or as safe as the operator is competent. Continued training and familiarization is essential.

An operator **MUST** be at the lower control station anytime the aerial is being operated.

Personnel should not climb the aerial tower until the lower controls operator indicates that it is safe to do so. The upper power switches must be turned off in the platform and at the turntable pedestal before climbing the ladder.

Rating of the aerial: Model SPI 95 - 1,000 lbs.

Rating in the bucket: Models SPI 95 - 500 lbs. while flowing water
or with charged waterway

Do not operate turntable controls while personnel are climbing the tower.

Personnel should use an approved life belt when operating on the aerial tower.

At night, the entire aerial tower should be well lighted.

Do not forcefully extend the end of the tower against a structure.

Never use the aerial as a battering ram.

Never use the aerial for pulling down walls or structural members.



Never willingly or intentionally abuse an aerial by careless handling, overloading, or use for which it was not designed.

Operate the aerial with deliberate motions and smooth application of power.

Training and practice with the apparatus on a regular basis is a must for safe operation.

Auxiliary ground pads should always be used under the outrigger feet when operating the aerial tower.

Do not use auxiliary ground pads under the rear jacks unless they are metal, as these jacks are used as a grounding point.

Safety pins on stabilizers shall always be in place.

Never move the vehicle with stabilizers in contact with ground.

Most problems encountered with operation of the tower are caused by inadequate maintenance. To keep the tower fully operational, routine lubrication policies should be followed.

The aerial should be inspected and tested annually in accordance with NFPA 1914, Testing Fire Department Aerial Apparatus.

Frequently inspect and maintain the chassis and running gear for proper mechanical conditions following the recommended schedules in this manual. The aerial tower is of no use unless it can be transported to where it is needed. Careful, safe driving rules should be observed for the same reason.

Carefully and frequently check and inspect the entire aerial for loose bolts or rivets, unlubricated bearing surfaces, bent, warped, or twisted parts, hydraulic leaks, defective electric control equipment, etc. Follow the recommended maintenance schedules in this manual.

All members should frequently practice the different phases of aerial operations.

 **Operator Manual**

Never set up the aerial on marshy ground, freshly filled ground, or other soft surface.

Never apply opposing alternating control when operating the aerial, either in a side-to-side motion, a front-to-rear motion, or an up-and-down motion. This may set up an accelerated oscillation, which could put undue strain on the structure and cause immediate or eventual failure of the aerial tower and injury to the occupants and bystanders.

Do not overload the aerial. Learn and observe the load limit indicated at the operator's positions.

When raising an aerial platform to rescue people at roofs or windows, avoid raising the platform in line with the people. Either raise off to one side and rotate to the people or raise perpendicular to them and rotate toward them. This is because panic-stricken persons seeing the platform within reach below them could try jumping into it.

Although the aerial is designed for one person setup, it is a good safety practice to designate a person to observe the right-side stabilizer when the stabilizers are being set up. This person can place the stabilizer pad and observe that it is placed evenly and correctly and that the stabilizer is set properly.

Many accidents with aerial devices nationwide occur during nonemergency operation. For this reason, the aerial should not be operated by one person alone. Operators checking out or operating the tower alone in front of the station can forget something or be overconfident and get into trouble. “Two heads are better than one”.

Never allow an untrained person or a person who is not thoroughly familiar with this aerial to operate it unless constantly supervised.



That person must as a result of proper training and practice:

1. Be capable of spotting the vehicle properly.
2. Be able to stabilize the vehicle properly.
3. Know the location of every control.
4. Know the function of each control and how it works.
5. Be able to operate all controls smoothly and safely.
6. Know the location of all safety devices, how they work, and how to operate them.
7. Be familiar with the loads that the aerial can safely accommodate under various operating conditions.
8. Be aware of how to operate the aerial under unusual circumstances.

When you consider the cost of an aerial platform, the lives that could be at stake, and the damage that could occur to the equipment, the importance of practice and training becomes very clear.



WARNING

Before operating this apparatus you must:

1. *Be thoroughly familiar with this instruction manual.*
2. *Be thoroughly trained in the operation of this apparatus.*
3. *Operate this apparatus in strict accordance with the manufacturer's recommendations.*
4. *Operate this apparatus in accordance with departmental rules and regulations.*
5. *Always set up the apparatus on concrete, blacktop, or gravel. Surface must be firm and solid.*

Failure to do so could result in injury or death to persons operating or working on or around this apparatus.

Failure to do so could also result in damage to this apparatus.

1.3 Safety Tags

On the following pages are the various safety tags found on the apparatus. All of the tags found here may not be used on your particular vehicle, as some are related to optional equipment. Included in this manual is a drawing showing the locations of these various tags on the apparatus. Should any of these tags become damaged or lost throughout the life of your vehicle, please contact Sutphen Corporation at 866-287-5549 for replacements.



Safety Tags

TAG 16



3.13 x 1.88



TAG 15



TAG 17



TAG 10




Sutphen-5

Operator Manual


TAG 22



7.25 x 3.50



6.63 x 2.75



FAMA 35

3.50 x 3.50



TAG 21





TAG 38-1



TAG 56



TAG 57



TAG 36



TAG 38



Sutphen-7

TAG 55

SAFETY INSTRUCTIONS

Jump Starting Precautions:

1. Jump starting with voltages greater than 16 volts DC or reversing the polarity will damage the engine computer.
2. Before attempting to jump-start the engine, make sure jumper cables are connected properly (positive to positive, negative to negative) and in the proper sequence (connect positive to positive first). Failure to do so can result in alternator and/or equipment damage.
3. Reversing battery polarity can also result in personal injury caused by a sudden discharge of electrolyte from the battery vents or by the sudden rupture of the battery case caused by an explosion of internal hydrogen gas.

Battery Charging Precautions

1. When using battery charger to charge batteries, set on 12 VOLT LOW CHARGE. Do not exceed a maximum of 16 volts DC.
2. Electrical damage or explosion can occur when charging batteries or boosting batteries.

Welding Precautions:

1. Serious damage to the ECM(s) and DDEC components may result from welding if all ECM connectors are not disconnected.
2. Serious damage to the multiplexed platform controls may occur if the power supply to them is not disconnected.


Sutphen-



TAG 66



TAG 281



TAG 59



TAG 58



Sutphen-9

Operator Manual

SAFETY INSTRUCTIONS

Before raising cab:

1. Read operator manual.
2. Provide sufficient cab clearance.
3. Secure or remove any loose items.
4. Make sure nothing is on the front bumper.
5. Make sure cab doors are shut and latched.
6. Make sure cab tilts fully and the safety bar engages.

Before lowering cab:

1. Make sure all service items are removed from engine area.
2. Raise cab to maximum height to release safety latch.
3. Make sure all personnel are clear of cab area.
4. Pull safety latch handle and hold out to lower cab.

TAG 323

TAG 328

⚠ DANGER



Fall Hazard

Do not open valves completely. Use only in an emergency.

TAG 322

⚠ WARNING



Crushing injuries may occur.

Stand clear when lowering cab.

TAG 327

SAFETY INSTRUCTIONS

Leveling System Override:

1. For emergency use only
2. Open only if automatic leveling system fails.
3. Open both valves one turn.
4. Read operator's manual before operating this equipment.

TAG 310

Computer Code Switch

TAG 324

Cab Tilt

Up



Down

TAG 325

Cab Tilt Safety Latch

Pull to Release

Sutphen-16




TAG 326




Sutphen-11

Operator Manual

TAG 385



TAG 365



TAG 355



Sutphen-12



▲ WARNING TAG 382

Serious injury or death may occur if inlets are supplied by a pressurized source when valve is closed.

TAG 381

ABS Code Switch

TAG 370

All equipment in the platform must be mounted in a holder. The total weight of equipment should not exceed 80 lbs.

7.25 x 3.50

▲ WARNING

Only trained personnel should operate this equipment. Personnel connecting supply or discharge hoses must be trained to recognize and respond to water hydraulics hazards and component limitations.

Do not operate or service until you have read, understood, and been trained and qualified on the procedures found in the latest editions of NFPA standards including 1511, 1451, 1500; IFSTA Handbooks; and the operation and service manuals supplied with this equipment. Replacement manuals are available from the manufacturer of this apparatus. Operating or servicing without knowledge or training may lead to injury or death for you or others.

6.63 x 2.75

▲ WARNING

Only trained personnel should operate this equipment. Personnel connecting supply or discharge hoses must be trained to recognize and respond to water hydraulics hazards and component limitations.

Do not operate or service until you have read, understood, and been trained and qualified on the procedures found in the latest editions of NFPA standards including 1511, 1451, 1500; IFSTA Handbooks; and the operation and service manuals supplied with this equipment. Replacement manuals are available from the manufacturer of this apparatus. Operating or servicing without knowledge or training may lead to injury or death for you or others.

FAMA 25

TAG 375

▲ CAUTION

Properly set rear jacks before raising the boom to load hose, fill water tank, etc.

Failure to do so may result in body or chassis damage.

TAG 368

To Engage PTO:

1. Bring engine to idle.
2. Move PTO switch to ON position.
3. Confirm that PTO dash light is on.
4. Resume operations.


Sutphen-13

Operator Manual

TAG 407




TAG 417




TAG 416



7.25 x 3.50



6.63 x 2.75



FAMA 32

TAG 410



TAG 395



3.50 x 3.50



Sutphen-14



TAG 405

⚠ DANGER

Electrocution Hazard

Death or serious injury may result from contact with this vehicle if it should be electrically charged.

Maintain 17 foot minimum clearance from all power sources during aerial operations.

Pump operator must use pull-out safety platform during aerial operations.

Always designate a spotter at pedestal to help avoid power lines during aerial operations.

Avoid simultaneous contact with truck and ground during aerial operations.

Stuphen-15

⚠ DANGER

Electrocution Hazard - Equipment is not insulated

NEVER approach or contact power lines with any part of this equipment.

Keep 50 feet from power line if voltage is not known.

Keep 20 feet from power line 350 kilovolts or less.

Account for swaying motion of power lines and apparatus.

Use light to search for power lines in the dark.

Do not step off a charged vehicle.

Approaching or contacting a power line will injure or kill.

FAMA36

Do not paint over this label. Replace if damaged or lost.

⚠ WARNING

Fall Restraint Required

All personnel on aerial ladder or platform must wear safety harness with restraint belt properly attached to the device.

Fall will injure or kill.

FAMA34

Do not paint over this label. Replace if damaged or lost.

7.25 x 3.50

⚠ WARNING

Fall Restraint Required

All personnel on aerial ladder or platform must wear safety harness with restraint belt properly attached to the device.

Fall will injure or kill.

FAMA34

Do not paint over this label. Replace if damaged or lost.


6.63 x 2.75

FAMA 34

Operator Manual




TAG 427




TAG 440



TAG 438



FAMA 37



643 x 275




TAG 436



FAMA38 Do not paint over this label. Replace if damaged or lost.



TAG 426



TAG 425



TAG 424



TAG 435

Sutphen-16



TAG 406

| | | |
|-----|------------------------|------|
| UP | Front Axle Lock | DOWN |
| RET | Left Front Stabilizer | EXT |
| RET | Left Rear Stabilizer | EXT |
| RET | Right Front Stabilizer | EXT |
| RET | Right Rear Stabilizer | EXT |
| UP | Right Stabilizer | DOWN |
| UP | Left Stabilizer | DOWN |
| UP | Rear Stabilizer | DOWN |

TAG 414

INSTALL SAFETY PINS

⚠ WARNING

Inspection Required
Follow the instructions in the operator's manual and NFPA 1911 for daily, frequent, and annual inspection and maintenance.

Operation of a poorly inspected aerial device may injure or kill.

FAMA39 Do not paint over this label. Replace if damaged or lost.

7.25 x 3.50

⚠ WARNING

Operator Attention Required
Trained operator must remain at primary controls any time there are personnel on the device.
Do not operate this device using platform or tip controls without a trained operator at the primary controls at all times.
Be alert for changing conditions and be prepared to remove device personnel from danger.
Failure to comply may injure or kill.

FAMA 47 Do not paint over this label. Replace if damaged or lost.

6.63 x 2.75


⚠ WARNING

Operator Attention Required
Trained operator must remain at primary controls any time there are personnel on the device.
Do not operate this device using platform or tip controls without a trained operator at the primary controls at all times.
Be alert for changing conditions and be prepared to remove device personnel from danger.
Failure to comply may injure or kill.

FAMA 47 Do not paint over this label. Replace if damaged or lost.

Operator Manual

TAG 431



CHASSIS DATA

Sutphen Corporation
7000 Columbus-Marysville Road
Amlin, OH 43022
(800) 848-5860


CHASSIS FILTERS

| | |
|--|--|
| CHASSIS ENGINE OIL FILTER PART NO. | |
| TRANSMISSION OIL FILTER PART NO. | |
| CHASSIS AIR CLEANER FILTER PART NO. | |
| CHASSIS FUEL FILTER PRIMARY PART NO. | |
| CHASSIS FUEL FILTER SECONDARY PART NO. | |
| CHASSIS ENGINE WATER FILTER PART NO. | |
| AIR DRYER ASSEMBLY FILTER PART NO. | |
| AERIAL HYDRAULIC FILTER CARTRIDGE PART NO. | |

CHASSIS SPECIFICATIONS

| | | | |
|-------------|--|---------------|--|
| MODEL | | TRUCK NO. | |
| FRONT TIRES | | REAR TIRES | |
| ENGINE | | | |
| SERIAL NO. | | NO. CYLINDERS | |
| BORE | | STROKE | |
| H.P. SAFE | | DISPLACEMENT | |
| PAINT COLOR | | | |

TAG 430



Sutphen Corporation
7000 Columbus-Marysville Road
Amlin, OH 43022
(800) 848-5860

PUMP DATA

| | | | | |
|----------------|--------------|----------------|-----------------|-------------------|
| | | PUMP MAKE | HALE | |
| | | GPM | PRESSURE | ENGINE RPM |
| | | XXXXXX | 150 PSI | XXXXXX |
| | | XXXXXX | 200 PSI | XXXXXX |
| | | XXXXXX | 250 PSI | XXXXXX |
| CAPACITY | 1500 GPM | GOVERNOR SPEED | 2100 | RPM |
| MODEL NO. | QMAX 150-23S | GEAR RATIO | 2.28 | TO 1 |
| SERIAL NO. | QMAX 150-23S | | | |
| PRODUCTION NO. | QMAX 150-23S | | | |

Sutphen-18



TAG 434




! WARNING

Keep legs and feet inside kick gaurd during aerial operations. Failure to do so may result in serious injury or death.

| POWER SOURCE SPECIFICATIONS | |
|--------------------------------------|------------------------|
| OPERATIONAL CATEGORY | CONTINUOUS DUTY RATING |
| RATED VOLTAGE(S) AND TYPE (AC OR DC) | XXXXXX |
| PHASE | XXXXXX |
| RATED FREQUENCY | XXXXXX |
| RATED AMPERAGE | XXXXXX |
| CONTINUOUS RATED WATTS | XXXXXX |
| POWER SOURCE ENGINE SPEED | XXXXXX |

TAG 433

TAG 432




FLUID DATA

Sutphen Corporation
7000 Columbus-Marysville Road
Amlin, OH 43022
(800) 848-5860

| | | QTY. | TYPE | | | QTY. | TYPE |
|--|--|------|------|---------------------------------|--|------|------|
| CHASSIS ENGINE OIL | | | | CAB TILT MECH. FLUID | | | |
| CHASSIS ENGINE COOLANT | | | | TRANSFER CASE FLUID / AUTO LUBE | | | |
| CHASSIS TRANSMISSION FLUID | | | | EQUIPMENT RACK FLUID | | | |
| PUMP TRANSMISSION FLUID | | | | GENERATOR SYSTEM LUBRICANT | | | |
| PUMP PRIMER FLUID | | | | AERIAL-TOWER HYDRAULIC FLUID | | | |
| DRIVE AXLE LUBRICATION FLUID | | | | LEVELING SYSTEM FLUID | | | |
| AIR-CONDITIONING REFRIGERANT FLUID | | | | FUEL TANK DIESEL NO. 2 | | | |
| AIR-COND. LUBRICAT. OIL SYS. LUBRICANT | | | | FRONT TIRE COLD PSI | | | |
| POWER STEERING FLUID | | | | REAR TIRE COLD PSI | | | |
| MONTH-YEAR BUILT | | | | DATE SHIPPED | | | |
| VEHICLE IDENTIFICATION NO. | | | | | | | HS- |

Sutphen-19

Operator Manual



TAG 451

TAG 448

WHEN DIFFERENTIAL LOCK IS ENGAGED, THE MAXIMUM SPEED IS 25 MPH

TAG 449

CAUTION
When filling water tank, do not exceed 100 psi. Failure to do so could cause the tank to rupture.

TAG 454

WARNING
Do Not Exceed Wattage Rating of Generator. Generator may be Permanently Damaged and Void Warranty.

TAG 452

GEN. PTO

TAG 455

Ladder Belt Tie-Off Point
WARNING
Not For Rescue or Rappelling
250lb. Max.

Sutphen-21



Warning/Danger/Caution Labels List


| | |
|----------------|---------------------------------|
| TAG 10 | ALIGNMENT LIGHT |
| TAG 15 | DO NOT MODIFY |
| TAG 16 | DO NOT GET OIL IN EYES |
| TAG 17 | STAND ON STEP - ELECTROCUTION |
| TAG 18 | PINCH POINT |
| TAG 19 | CRUSHING INJURY |
| TAG 20 | ELECTROCUTION HAZARD |
| TAG 21 | LIFTING EYE |
| TAG 22 | DO NOT CLIMB BOOM |
| TAG 23 | AERIAL DATA PLACARD |
| TAG 36 | FIRE MAY OCCUR |
| TAG 37 | SEAT BELTS FASTENED |
| TAG 38 | BREATHING OF FUMES |
| TAG 38-1 HORZ. | BREATHING OF FUMES |
| TAG 55 | JUMP STARTING PRECAUTIONS |
| TAG 56 | EXPLOSION MAY OCCUR - BATTERIES |
| TAG 57 | OCCUPANTS MUST BE SEATED |
| TAG 58 | DO NOT USE AUXILIARY BRAKING |
| TAG 59 | STAY CLEAR OF FAN |
| TAG 66 | STAND CLEAR OF OUTRIGGER |
| TAG 281 | TIRE CHAIN OPERATION |
| TAG 282 | STABILIZER SYSTEM |
| TAG 310 | COMPUTER CODE SWITCH |
| TAG 322 | STAND CLEAR - LOWERING CAB |
| TAG 323 | BEFORE RAISING CAB |
| TAG 324 | CAB TILT UP & DOWN |
| TAG 325 | CAB TILT SAFETY LATCH |
| TAG 326 | DO NOT RAPPEL FROM AERIAL |
| TAG 327 | LEVELING SYSTEM OVERRIDE |
| TAG 328 | FALL HAZARD |
| TAG 353 | SUTPHEN - TEAMSTER LOGO |
| TAG 365 | CARRY MAX. PERSONNEL |
| TAG 368 | TO ENGAGE PTO |
| TAG 370 | EQUIPMENT MOUNTED |
| TAG 375 | SET REAR JACKS |
| TAG 381 | ABS CODE SWITCH |
| TAG 385 | POSITIVE/NEGATIVE |
| TAG 395 | FLOW OR RECIRCULATE |


Operator Manual
Warning/Danger/Caution Labels List - Continued

| | |
|---------|-----------------------------------|
| TAG 405 | ELECTROCUTION HAZARD |
| TAG 407 | PEDESTAL AREA |
| TAG 408 | LOCK - DOWN |
| TAG 409 | EXITING BUCKET |
| TAG 410 | EXITING CAB |
| TAG 414 | INSTALL SAFETY PINS |
| TAG 416 | SAFETY CHAIN FASTENED |
| TAG 417 | ENGAGE GENERATOR |
| TAG 424 | AIR HORN |
| TAG 425 | ELECTRIC SIREN |
| TAG 426 | MECHANICAL SIREN |
| TAG 427 | DO NOT WALK ON SURFACE |
| TAG 430 | PUMP DATA PLACARD |
| TAG 431 | CHASSIS DATA PLACARD |
| TAG 432 | FLUID DATA PLACARD |
| TAG 433 | POWER SOURCE SPECS. |
| TAG 434 | KEEP FEET INSIDE KICK GUARD |
| TAG 435 | KUSSMAL AUTO-PUMP DRAIN |
| TAG 436 | FRONT SUCTION - RAISING CAB |
| TAG 438 | WATERWAY VALVE OVERRIDE |
| TAG 440 | EQUIPMENT LIMITS - 5 LB. (BUCKET) |
| TAG 443 | PUMP DATA PLACARD (METRIC) |
| TAG 444 | TIRE PRESSURE FR. 120 R. 95 |
| TAG 445 | TIRE PRESSURE FR. 120 R. 110 |
| TAG 448 | DIFFERENTIAL LOCK ENGAGEMENT |
| TAG 449 | WATER TANK REFILL |
| TAG 451 | HYDR. COMPT. JACK CONTROL 95/100 |
| TAG 452 | GENERATOR PTO |
| TAG 453 | TIRE PRESSURE (AERIAL) |
| TAG 454 | GENERATOR |
| TAG 455 | LADDER BELT TIE-OFF POINT |



Safety Tags Location



| | |
|---|-----------|
| SUTPHEN CORPORATION 1000 SUTPHEN DRIVE • SUDBURY, ONTARIO • CANADA | |
| REV. NO. | REV. DATE |
| 1001/08 | |
| TITLE | |
| TLB | |
| DESCRIPTION | |
| NONE | |
| TAG LOCATIONS | |
| 95 - 100' | |

NEW 95-100.tif

Operator Manual

REAR WARNING TAGS

Rear, Bucket

- 10140837 - LABEL Stokes Basket Tie-Off Point

Rear, Bucket

- 10063859 - TAG Stokes Arm Capacity

Rear, Chevrons

Modify the following tag:

- 10063871 - Tag Ladder Belt Tie Off Warning
As is shown in the image below by cutting below "Ladder Belt Tie Off Point" part of label

Rear, Rear of Truck

- 10000087 - NAMEPLATE Sutphen Logo 5m 7.875" x 3.35" w/psa

Rear, Bucket Pivot

- 10063856 - TAG Bucket Static Load

SUTPHEN CORPORATION












CONSTRUCTION INDUSTRY IS THE CONFORMING AND PROGRESSIVE PEOPLE OF SUTPHEN CORPORATION. THE USE, APPLICATION OR EXPOSURE TO ANY ELEMENT PART OF THE EQUIPMENT OR INFORMATION CONTAINED HEREIN IS STRICTLY PROHIBITED WITHOUT THE WRITTEN AUTHORIZATION OF SUTPHEN CORPORATION.

SUTPHEN CORPORATION









SPH_Labels A 8 OF 10



BUCKET WARNING TAGS

| | | | | | | | | | | | | | |
|--|---|---------|---|---|---|---|---|----------------|-----|-------|------------|---|---------|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | | | | | | |
| A | <div style="display: flex; justify-content: space-between;"> <div style="width: 48%;"> <p>Bucket, Rear</p> <ul style="list-style-type: none"> 10063811 - TAG Exiting Cab 3000588-024  </div> <div style="width: 48%;"> <p>Bucket, Rear</p> <ul style="list-style-type: none"> 10063011 - TAG Exiting Cab 3000598-024  </div> </div> | | | | | | A | | | | | | |
| B | <div style="display: flex; justify-content: space-between;"> <div style="width: 48%;"> <p>Bucket, Control Panel</p> <ul style="list-style-type: none"> 10114349 - Bucket Levelling, E-STOP Disable 10013892 - LABEL, AERIAL ALARMS SIZE 8, 10012500 Bezel IF APPLICABLE 10012174 - INTERLOCK OVERRIDE SIZE 8 BLAC, 10012500 Bezel IF APPLICABLE 10134891 - LABEL, BREATHING AIR ALARM  </div> <div style="width: 48%;"> <p>Bucket, Control Panel</p> <ul style="list-style-type: none"> 10063858 - TAG Lifting Eye Capacity 10063754 - Platform Equipment 300103-0001 10114870 - TAG Electrocutation Hazard Size A 10114859 - TAG Fall Hazard Restraint Required 10114816 - TAG Trained Operator Required 10114872 - TAG Failure Do Not Exceed Capacity 10063700 - Aerial Rappel Warning 3001033-001  </div> </div> | | | | | | B | | | | | | |
| C | <div style="display: flex; justify-content: space-between;"> <div style="width: 48%;"> <p>SECTION A-A SCALE 1 : 20</p>  </div> <div style="width: 48%;"> <p>SECTION B-B SCALE 1 : 20</p>  </div> </div> | | | | | | C | | | | | | |
| D | <p>Bucket, Rear</p> <ul style="list-style-type: none"> 10063871 - TAG Ladder Belt Tie Off Point  | | | | | | D | | | | | | |
| E | <p>Bucket, Rear</p> <ul style="list-style-type: none"> 10011833 - TAG 125V 15A, 1PH or C BLACK ON SILVER, 10012500 Bezel 10011889 - TAG CFI breaker sz C BLACK ON SILVER, 10012500 Bezel  | | | | | | E | | | | | | |
| F | <div style="display: flex; justify-content: space-between;"> <div style="width: 48%;">  </div> <div style="width: 48%;">  </div> </div> | | | | | | F | | | | | | |
|  <p style="text-align: right;">SUTPHEN CORPORATION</p> | | | | | | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;">DRAWING NUMBER</td> <td style="width: 20%;">REV</td> <td style="width: 20%;">SHEET</td> </tr> <tr> <td>SPH_Labels</td> <td>A</td> <td>9 OF 10</td> </tr> </table> | | DRAWING NUMBER | REV | SHEET | SPH_Labels | A | 9 OF 10 |
| DRAWING NUMBER | REV | SHEET | | | | | | | | | | | |
| SPH_Labels | A | 9 OF 10 | | | | | | | | | | | |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | | | | | | |

Operator Manual

| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | | | | | | | | |
|--|---|---|---|---|--|---|---|--|--|---|--|---|--|--|--|--|
| BUCKET WARNING TAGS CONT'D | | | | | | | | | | | | | | | | |
| A | <p>Bucket, Officer Side</p> <ul style="list-style-type: none"> • 10117474 - TAG Manual Override, 10012479 Bezel • 10063702 - Levelling System Override, 3000598-0031 Bezel • 10063704 - OPEN VALVES FALL HAZARD, 3000598-0028 Bezel  | | | | <p>Bucket, Driver Side</p> <ul style="list-style-type: none"> • 10012269 - WATER CURTAIN, SIDE B BLACK  | | | | | | | | | | | |
| B | | | | | | | | | | | | | | | | |
| C | <p>Bucket, Top</p> <ul style="list-style-type: none"> • 10063871 - TAG Ladder Belt Tie Off Point  | | | |   | |  | | | | | | | | | |
| D | | | | | | | | | | | | | | | | |
| E | <p>Boom, Ladder</p> <ul style="list-style-type: none"> • 10114973 - TAG Pinch Hazard Moving Rungs  | | | | | | | | | | | | | | | |
| F | | | | | | | | | | | | | | | | |
|  <p>SUTPHEN CORPORATION</p> <p style="font-size: small;">CONFIDENTIAL: THIS DOCUMENT IS THE CONFIDENTIAL AND PROPRIETARY PROPERTY OF SUTPHEN CORPORATION. IT IS TO BE USED ONLY FOR THE PURPOSES SPECIFIED IN THIS DOCUMENT. REPRODUCTION OR DISCLOSURE IN ANY MANNER WITHOUT THE WRITTEN AUTHORIZATION OF SUTPHEN CORPORATION IS STRICTLY PROHIBITED.</p> | | | | | | | | <p style="font-size: x-small;">DocuPrint Version</p> <p style="font-size: small;">SPH_Labels</p> | | <p style="font-size: x-small;">Rev</p> <p style="font-size: small;">A</p> | | <p style="font-size: x-small;">Page</p> <p style="font-size: small;">10 OF 10</p> | | | | |
| F | | | | | | | | | | | | | | | | |



| REAR WARNING TAGS | | |
|----------------------------|--|----------|
| Rear, Bucket | 10140837 - LABEL Stokes Basket Tie-Off Point | N/A |
| | 10063859 - TAG Stokes Arm Capacity | N/A |
| Rear, Chevrons | 10063871 - TAG Ladder Belt Tie-Off Warning | N/A |
| | 10114871 - TAG Electrocutation Hazard Large | N/A |
| Rear, Bucket Pivot | 10063856 - TAG Bucket Static Load | N/A |
| Rear, Rear of Truck | 10003087 - NAMEPLATE Sutphen Logo Sm 7.875" x 3.5" w/psa | N/A |
| BUCKET WARNING TAGS | | |
| Bucket, Rear | 10063811 - TAG Exiting Cab 3000588-024 | N/A |
| | 10063871 - TAG Ladder Belt Tie-Off Warning | N/A |
| | 10011833 - TAG 125V 15A 1PH sz C BLACK ON SILVER | 10012500 |
| | 10011889 - TAG GFI breaker sz C BLACK ON SILVER | 10012500 |
| | 10063858 - TAG Lifting Eye Capacity | N/A |
| | 10063754 - Platform Equipment 300103-0001 | N/A |
| | 10114870 - TAG Electrocutation Hazard Size A | N/A |
| | 10114873 - TAG Pinch Hazard Moving Rungs | N/A |
| | 10114876 - TAG Trained Operator Required | N/A |
| | 10114872 - TAG Failure Do Not Exceed Capacity | N/A |
| | 10063700 - Aerial Rappel Warning 3001033-001 | N/A |
| Bucket, Control Panel | 10114349 - Bucket Leveling, E-STOP Disable | N/A |
| | 10013892 - LABEL, AERIAL ALARMS SIZE B | 10012500 |
| | 10012174 - INTERLOCK OVERRIDE SIZE B BLAC | 10012500 |
| | 10134891 - LABEL, BREATHING AIR ALARM | N/A |
| Bucket, Officer Side | 10117674 - TAG Manual Override | 10012479 |
| | 10063702 - Leveling System Override 3000588-0031 Bezel | N/A |
| | 10063704 - OPEN VALVES FALL HAZAR 3000588-0028 Bezel | N/A |
| Bucket, Driver Side | 10012269 - WATER CURTAIN SIZE B | N/A |
| Bucket, Top | 10063871 - TAG Ladder Belt Tie-Off Warning | N/A |
| Bucket, Ladder | 10114873 - TAG Pinch Hazard Moving Rungs | N/A |

1.4 Cab Setup Procedures

Locating the Vehicle

1. Spot the rig about 30 to 35 feet from the building when possible. This will give you maximum vertical coverage of the building.
2. Set the parking brake.
3. Place the transmission in neutral.
4. Make sure apparatus is on firm pavement, and that it is clear of overhead obstacles, such as poles, wires, building overhang, etc.
5. Make sure that the outriggers or rear jacks are not going to sit upon manhole covers, drains, or grates in the street.
6. Good judgement must be used in locating the apparatus at the fire scene. Ideal conditions may not always exist, so caution must be used to determine as safe a location as possible for the apparatus.

Activating the Hydraulic System

There is a PTO which operates the hydraulic pump, providing hydraulic pressure to the system.

1. Engine must be at idle RPM.
2. Be sure there is at least 90 lbs of air pressure on truck air system.
3. Truck must be at complete stop, parking brake set, and transmission in neutral (N).
4. Flip rocker switch for Aerial PTO. A pilot light (1) will come on when the PTO is engaged.

The cab controls are now set to operate the hydraulic system.



If not using the fire pump, or if your vehicle does not have a fire pump, proceed to **AERIAL TOWER SETUP** found later in these instructions.



Mode Button and Pilot Light (1) for Generator PTO

1.5 Cab Setup for Fire Pump Operation

NOTE: See **Fire Pump Manual** for more detailed information.

1. Truck must be stopped and parking brake set.
2. Truck transmission must be in neutral (N) position.
3. Engine must be at idle RPM

Operator Manual

4. Move the pump shift lever from ROAD position to PUMP position. Notice the green PUMP ENGAGEMENT light will come on. This is done by raising the yellow locking collar and pulling back on the lever.



Air Pump Shift



Electronic Pump Shift

5. (Only if the pump is “wet”)

Shift transmission to drive (D) (1-4) position. Power from the engine is now being transferred to the pump drive gear and pump impellers are turning. Observe the illuminated green OK TO PUMP indicator light next to the shift lever. The lock-up for the automatic transmission will be engaged when the transmission is shifted into drive (D). The pump shift lever will hold the transmission in the pumping gear position.

If the light is not on, the pump is not engaged. Repeat steps 1-5 and observe for pump engagement.

6. To have the pump ready for operation later, leave transmission selector in neutral (N). For pump operation, simply put transmission selector in drive (D) (1-4).



NOTE: Upon arrival at a structure fire or other incident where the tower is not immediately needed, but the fire pump is being used, it is good practice to place the PTO in gear before placing the fire pump in gear. Should a need to use the tower arise, and the fire pump is being used, the stabilizers can be set, and the tower is then ready for immediate use. If the PTO was not engaged before the pump was set up, it would be necessary to slow the engine to an idle to engage the PTO, jeopardizing firefighting operations.



CAUTION

Attempting to place the PTO in gear will result in serious damage to the PTO and transmission unless engine RPMs are at idle - approximately 700 RPM.

1.6 Aerial Setup Procedures

Your Sutphen Aerial Platform has been designed to work in out-of-level conditions (See section 1.7.9 and 1.7.11 below for details). You can work in high winds up to 35 miles per hour. The aerial can shed ice buildup caused by freezing rain and/or nozzle spray.

1.7

Stabilizing System

This system consists of seven double-acting hydraulic cylinders. Two of the cylinders permit the extension of the main outriggers to be located in such a manner as to allow for curbs or chuckholes or operating in alleys or narrow locations between other vehicles. All cylinders are provided with double pilot-operated check valves to ensure constant holding position of any outrigger after it has been set in position. The main stabilizers (outriggers), front and rear, are provided with large steel feet that swivel to allow the them to adjust to the contour of the ground surface. Auxiliary ground jack pads are provided for the outriggers and should be used every time the tower is set up. A front jack system is provided on some models.



DANGER

Always set up the apparatus on concrete, blacktop, or gravel. Surface must be firm and solid. Soil/ground surfaces are not desirable, as the outrigger may sink into the ground, causing a tipover. Soil surfaces that seem stable upon setup may erode with fire scene runoff water, thus making them unstable. Asphalt parking lot surfaces are typically thin and in hot weather may allow the outrigger to sink through, especially if the subsurface material is sand.



Ground Jack Controls

1. Move to the ground jack controls (1), located in the compartment directly behind the cab on the driver's side of the truck.
2. There are six or seven handles on the hydraulic control valve.
3. Look at the level indicator located on rear of cab to see how far out-of-level the apparatus is.



4. Making sure all is clear, extend the left-hand outrigger to the maximum extension. As this outrigger starts out, a warning alarm will sound and the short jack LEDs and JACKS NOT SET box on the turntable pedestal will turn on. This indicates that the jack system is not properly deployed but will silence as you complete the setup procedure.



Turntable Pedestal

▽ **Operator Manual**

5. Making sure all is clear, extend the right-hand outrigger to the maximum extension, observing the area through the large mirror provided on the rear of the cab. Although one person can perform this operation, it is safer and quicker to have someone else on the right side of the apparatus.



View of Right Outrigger in Mirror

6. Remove the auxiliary ground pads from their carriers inside the outrigger areas and place them directly under each outrigger foot.



Auxiliary Pad Under Outrigger



DANGER

Auxiliary ground pads must be placed under outrigger feet at all times. Failure to do so could cause a tipover resulting in serious injury or death and/or damage to the vehicle. Never put wood or nonmetallic jack pads down for rear jacks; use only metal for grounding.

7. Lower the left outrigger until it touches the auxiliary ground pad.
 8. Lower the right outrigger until it touches the auxiliary ground pad. View from mirror or spotter.
 9. Level the truck from **side to side**, if necessary, to work in a range of 5 degrees out-of-level as indicated by the green area on the level indicator. As long as the level is in the green area, you are allowed to operate.
 10. Pull both left and right outrigger down levers simultaneously to raise the front of the truck until the front tires clear the ground by (1") one inch. If using **Hendrickson Suspension**, lower the outriggers until the bulge is out of the tires.
 11. Lower the rear jacks so that the tires on the front axle just clear the ground. If using **Hendrickson Suspension**, lower rear jacks until bulge is back in the front tires.
- NOTE: At this point, the front tires should have come down to where they are just touching the ground. If using Hendrickson Suspension, at this point, there should be a bulge in the front tires.**

If working on a surface that is not level in the longitudinal (**Front to Rear**) axis of the truck, use the outriggers and the rear jacks to level the truck within 10 degrees.

NOTE: Depending on whether the grade is up or down, leveling will either raise the front tires off the pavement or lower them onto the pavement.

12. Your apparatus is equipped with cab (axle) jacks, which are two cylinders mounted to the chassis frame in the front wheelwell that push against the front axle. Push the front jack switch to fully extend them, which will isolate the front suspension.

1.8 Safety Pins




Installed Safety Pin

Install the pins only after the apparatus has been completely set up properly. The operator and his/her assistant are to show the pins to each other in the mirror before installing them.

Place the outrigger safety pins (1) in the lowest possible hole in the outrigger jack frames. The pins must be installed per instructions, as this completes the interlock system and allows power to be transferred to the upper controls.



NOTE: At this point, there will be four green lights lit on the interlock display panel in the hydraulic compartment and the audible alarm will have silenced and the short jack LEDs and JACKS NOT SET box on the pedestal will go out.



Interlock Display Panel

If the safety pin hole is near (1/2 inch or less) to the safety bar, go up to next higher hole. This will avoid having the pin pinched by cylinder creep that later will not allow you to remove pin when taking down the truck. At this point, reengage PTO and lower the outriggers until the safety pin is free and remove it.



DANGER

Always install safety pins on stabilizers. This will guard against a cylinder collapse caused by an internal leak, such as a damaged piston seal.

1.9 Transfer Fluid for Aerial Operation

Activate electrical power to the turntable pedestal by turning the UPPER POWER/HYD. TRANSFER switch in the hydraulic compartment to the ON position. This switch also allows fluid to be pumped to the aerial controls on the turntable.

SAFETY TIP: This switch may be used to disable the platform controls should someone on the ground observe an impending danger to those in the platform that they may not be aware of.

NOTE: This will also shut off power to the intercom system and the platform leveling system. For this reason, it is preferred to use the BUCKET CONTROL POWER switch on the pedestal, which only shuts off power to the platform controls.

With all outriggers and ground jacks properly set as described here, your aerial is designed to operate at its maximum height and horizontal reach with its rated payload without danger of harming personnel or equipment. Precaution must be taken to ensure that the aerial is operated so it does not strike the cab or any other portion of the apparatus during any operation. Water stream reactions may have some affect on certain functions of the tower. This is detailed under Waterway and Nozzles. Power lines should always be observed and avoided at all times.



DANGER

*When operating near power lines, pump operator must stand on the operator's step at all times during tower operation to help prevent operator from becoming the ground in the event tower comes in contact with power lines. Failure to do so could result in **SERIOUS INJURY OR DEATH**.*

Place wheel chocks in front of and behind the front tandem. Place the chock at the outside tires.



CAUTION

Always remove the chocks before releasing any of the ground jacks. Failure to do so may result in wedging the chock block so tightly against the tire tread that it cannot be removed.



1.10 Stabilizer Interlock System

This stabilizer interlock system is a series of position sensors that are specifically designed to ensure safe and proper setup of the apparatus for aerial operation.

When the outriggers begin to extend, an audible horn sounds and the JACKS NOT SET and short jacked LEDs on the turntable pedestal light. This indicates that the jack system is not properly set up or properly stowed. The alarm will silence and the light will go out when the jack system is properly set up or properly stowed.

When the ground jacks are set up according to the instruction previously found in this manual, one set of two sensors close when the stabilizers are fully extended and one set of two sensors close when the outrigger jacks have the safety pins installed.

The closing of these switches produces a signal which allows the aerial to be operated. The initial movement of the aerial from the cradled position locks the fluid transfer valve so that it cannot be operated again until the aerial is returned to the cradled or stowed position and both safety pins have been removed.

Stabilizer Interlock Override Procedure

Located on the left side of the hydraulic compartment switch panel and on top of the turntable pedestal are the stabilizer interlock override buttons. They are to be used only in extreme situations where one outrigger cannot be fully extended on the side opposite the side you are wanting to operate on. These buttons should be only used by personnel fully trained in the operation of the vehicle. This includes understanding the danger of an overturned vehicle caused by working over an unextended outrigger.

By simultaneously depressing the buttons, you can raise the aerial from the bed of the truck. After the aerial has cleared the bed, you may let go of the override buttons and the tower will continue to operate. Notice that when the aerial clears the bed, the audible alarm stops, but the OSB light remains on, reminding you that the truck is not set up properly.

After the tower is in operation, great concern shall be given to the position of the tower and shall never be rotated past the longitudinal centerline of the truck towards the “short jacked” side. The short jacked side of the truck should have the outrigger run out as far as possible, have the pad under the foot, and have the safety pin installed.

1.11 Rotation Interlock System

The rotation interlock system will allow the aerial to operate with only one outrigger fully extended and the other only partially extended. This condition is known as short jacking. This configuration may be required when operating in very narrow areas.

Both outriggers must be lowered properly and the safety pins must be installed properly for the aerial to operate.

In operation, the boom is permitted full unobstructed operation on the side of the fully extended outrigger. Operation is not permitted past the centerline of the truck towards the short jacked side of the truck.

When operating over the properly jacked side of the truck, and you rotate near the longitudinal centerline of the truck, the rotation interlock system will activate audible and visual alarms and put the aerial controls into CREEP MODE. As movement continues, the rotation will stop preventing movement over the short jacked side.

Movement will be allowed back towards the properly jacked side, but the controls will remain in CREEP MODE until the boom has cleared the zone that originally activated the CREEP MODE.

If, for some reason, the boom has drifted to the short jacked side of the truck, the controls will allow you to rotate back towards the centerline of the truck in whichever direction is closest.




1.12 Smart Boom Warning System

This system will warn you both audibly and visually of impending contact with either the cab or the body of the truck. **It will not stop movement of the boom!**

The system consists of sensors underneath the turntable that determine the radial location of the aerial and adjustable sensors on the left turntable side plate that determine the elevation of the aerial.

Located at the turntable pedestal and in the platform are graphic displays for the SMART BOOM WARNING SYSTEM and the ROTATION INTERLOCK SYSTEM. They provide visual indications of the current status of aerial operations.



**Display of Smart Boom Warning System
and Rotation Interlock System**

In operation, if the boom is positioned above the cab or body and is lowered to a point that the SMART BOOM WARNING SYSTEM is activated, the aerial controls will be put into a slow motion CREEP MODE and visual and audible alarms will be activated. The aerial controls will remain in CREEP MODE as long as the boom is inside the CONTACT ZONE.


Operator Manual

If the boom is in a low elevation over one of the outriggers and is rotated toward the cab or body, the SMART BOOM WARNING SYSTEM will be activated when in close proximity.

When in a CREEP MODE, full operational speed may be regained by either elevating or rotating the boom until it is clear of the CONTACT ZONE.

When a CONTACT ZONE alarm is sounding, you may cancel the audible portion of the alarm by pushing the ALARM SILENCE button. This will only cancel it at the operator's station where you are present. When the boom is moved to a location outside the CONTACT ZONE, the audible alarm will be automatically reset.

1.13 Aerial Operational Controls



Pedestal Controls



Platform Controls

The aerial may be operated from the turntable pedestal or the platform. The platform controls are multiplexed electric-over-hydraulic, while the pedestal controls are manual hydraulic.

You will notice that both sets of controls are “proportional”, meaning that the operations can be “feathered” to produce gentle movements.



The pedestal controls will always override the platform controls. If the platform operator is moving in one direction, the pedestal operator can stop or even reverse the operation if an emergency need arises. The power to the platform controls can be turned off at the pedestal or in the ground jack controls.



DANGER

Never operate the tower without first deploying the stabilizer jacks with proper auxiliary ground pads beneath them.

Raise/Lower

Raise the tower by moving the right control lever in the direction indicated.

Lower the tower by moving the right control lever in the direction indicated.

NOTE: Controls in platforms are duplicates of lower controls.

When raising the tower from the cradle, the first motion of the tower should be "up", and this should continue until tower is well above the truck.



CAUTION

Observe that the tower has cleared the truck body, cab, and lights before rotating. The recommended procedure for aerial operation is a slow, steady movement of the control lever which, will produce a smooth operation.



CAUTION

Rapid movement or jerking of the control levers may result in rough jerking of the aerial imposing excessive loading on the tower structure. This kind of operation is unsafe and will lead to premature wear and, at the extreme, possible structure failure.



DANGER

When raising the aerial, extreme caution should be used near power lines. The operator must observe the tower structure from base to tip to ascertain that the tower is in the clear.

The tower can be elevated from minus (-) 3 degrees to plus (+) 80 degrees from horizontal, while in any position of extension and any position of rotation.



WARNING

There should be an operator at the lower control station any time the aerial is being used. The lower controls can override the platform controls should an emergency or dangerous situation come up or if the platform operator should become incapacitated because of smoke or other problems.

Extend/Retract

Extend the tower by moving the left control lever in the direction indicated.

Retract the tower by moving the left control lever in the direction indicated.

Rotation

Rotate the tower to the **left** by moving the center control lever in the direction indicated.

Rotate the tower to the **center** by moving the right control lever in the direction indicated.

The tower is capable of continuous 360-degree rotation, either to the **left** or the **right**.

The operator should never change direction of rotation without first bringing the aerial to a gentle stop.

High-Speed Control

On the floor of the turntable and on the floor of the platform there is a HI-SPEED switch provided to increase the engine speed and hydraulic pressure simultaneously. This switch is to be used only to increase the speed of operation of the aerial.



CAUTION

Caution must be used in the use of this HI-SPEED switch.

NOTE: When in pump mode, the switch is disabled.

NOTE: When using the HI-SPEED switch, first have the operational control lever being used in position before engaging the HI-SPEED switch. When coming off HI-SPEED, first release the switch, then release the control lever as desired to complete movement and give a smooth, safe operation.

When extending the aerial and using the HIGH-SPEED control, be sure to release the HIGH-SPEED switch before reaching maximum extension. Aerial extension will stop at maximum extension. (There is no signal device for indicating full extension.)

When retracting the aerial and using the HIGH-SPEED switch, be sure to release the HIGH-SPEED switch before reaching full retracted position.

NOTE: The aerial is capable of continuous 360-degree rotation to the left or right. If it becomes necessary to rotate at a faster speed, the HI-SPEED switch can be used. Be sure the rotation control lever is engaged before engaging the HI-SPEED switch. When coming off HI-SPEED, release the HI-SPEED switch before releasing the rotational control lever. This will give a nice smooth operation.



CAUTION

While rotating the tower, the operator should not change directions without first permitting the tower to come to a complete stop!

In the event the operator accidentally changes rotation directions without the tower coming to a complete stop, there is a built-in relief valve provided to reduce the shock of such a happening. **IN NO WAY SHOULD THIS BE AN OPERATIONAL PRACTICE!**

Auxiliary Hydraulic Power Switch

The auxiliary hydraulic power switch is located in the hydraulic compartment panel. Auxiliary power is used in the event of a main hydraulic pump failure or in case the truck engine fails. It consists of an electric motor, operated from the truck battery system, which operates an auxiliary hydraulic pump.

Operate the motor by turning the auxiliary power switch to the ON position.

All tower functions can be operated on auxiliary power.



CAUTION

Prolonged operation may cause the motor to overheat. The operator should avoid overheating and burning out the motor. If the motor becomes hot, shut down and allow to cool. Failure to do so could result in serious damage to the motor. Run for two minutes and cool for five minutes.

1.14 Water Delivery System

Telescopic Waterway

The waterway through which water from the pump or manifold assembly is transferred to the nozzle is a four-section, telescopic aluminum device. It is located within the tower sections mounted and cushioned to eliminate any undue stress or strain under tower operating conditions.

The waterway is fed from the pump through the main feed line, coming up through the turntable and passing through a large stainless steel flex tube, which is directly attached to the waterway. Special packing gland seals are provided at the attachment location of each waterway section to ensure constant alignment and eliminate wear to the tubes.

The feed line for the waterway is provided with an electric ball valve at the lower entrance of the water supply. For best results, open and close valve at idle pressure. This is to ensure that no undue water surge is applied to the waterway. A manual override for this valve is provided in the right-side pump panel if your truck has a Hale pump and under the truck if your truck has a Waterous pump. In both cases, a hex nut for manual valves or a hand wheel for electric valves can be used to open the valve.



NOTE: This override turns clockwise to open.

Two relief valves are installed in the waterway system to help prevent excessive pressure in the waterway (one under the truck and one just behind the platform). Should the operator retract the tower without opening the waterway drain or should pump pressure exceed the capacity of the waterway, the relief valves will open. The **lower** relief valve is set at **225** psi discharge pressure, and the **upper** is set at **165** psi. The waterway drain should always be left open when the tower is not being operated.

Maintenance is minor and is described in the section under lubrication.



CAUTION

Before retracting the tower, make sure that the nozzles and the waterway drain are open to avoid compressing the water in the waterway. Failure to do so can result in serious damage to the waterway.

Platform Water System

There are two turrets with adjustable stream nozzles provided on each side of the platform attached to the supporting yoke assembly. Gear-driven butterfly valves are installed ahead of the turrets to allow smooth control of the water coming to the turrets, eliminating the possibility of surges (water hammer) through the waterway system. The water system is rated for up to **1500 gpm**. The rating in the bucket, while waterway is charged or flowing water, is **500 lbs**.


Both nozzles may be operated simultaneously or individually. The nozzles are rated to deliver the capacity of the turrets.

There are auxiliary connections on the water system at the platform for standpipe operations. They are 2 ½ inches with a 1 ½-inch reducer and cap. They are controlled by separate gate valves.


▽ **Operator Manual**

1.15 Cold Weather Operations

Draining the Waterway



**Truck has Automatic
Drain Valve Yoke**



Water Curtain Valve

If operating with your aerial flowing water during freezing conditions, these instructions must be followed for draining the waterway to help prevent potential freezing.

Immediately after shutting off the water flow to the waterway, open the nozzles 50% in the platform, the water curtain (2), and the waterway drain valve (1) (at the pump panel). To expedite the draining process, retract the aerial completely and elevate as high as practical.



CAUTION - Cable Track System

Periodic extension and retraction during icing conditions can reduce the possibility of ice forming. Never operate the the ladder when ice has clearly formed or may have formed inside the cable track. Damage may occur if ice builds up inside of the cable track. Ice must be allowed to melt to avoid damaging the cable track system.

1.16 Draining the Fire Pump

Open all master and individual drain valves (suction and discharge) and open all valves, removing caps to make sure they drain completely.

Drain gauges on tower gauge panel.

When pump is completely drained, all individual drains may be shut, but the master drain should be left open until the fire pump is needed to be used.




1.17 Platform Mounting and Leveling System

The platform is suspended in the yoke, anchored on each side with special self-aligning bearings and special high-tensile steel bolts. The bolts that hold the bucket to the yoke have special locking devices to ensure positive, safe operation.

The platform is maintained in a level position relative to the turntable at all times. This is accomplished by a self-contained electrohydraulic system, eliminating any hydraulic lines up the tower. This system operates the hydraulic leveling motor. The pivot point of the platform is above the center line of the platform, providing a pendulum effect, reducing the energy required to level the platform. The system is electrically activated and kept level during any function of the tower. The pendulum effect of the platform will keep the platform level. This is an exclusive safety feature of this aerial.

Leveling System Override



Leveling System Override Valves

In case of failure, there are two needle valves (1) located on the right side of the end of the boom. Open these valves 1/4 of a turn and the hydraulic cylinder will operate with the weight in the platform, thus keeping the platform level.

1.18 Optional Breathing Air System

On the aerial platform, a life support breathing system is installed. This consists of a 4,500 psi, 6,000 psi or 7,000 psi air cylinder mounted in brackets on the turntable, a shutoff valve, and a constant flow air regulator.

Air is piped from the regulator by a heavy-duty air hose through a cable track located in the platform.

In the platform, there is an air filter, and two air connections are provided. There are boxes mounted on the platform to store masks in when not in use.

Air to the mask can be regulated from the air supply cylinder by presetting the regulator at approximately 120 psi (Refer to air mask manufacturers recommendations). Once the air pressure regulator has been set, all that is required to provide air to the platform is to turn air on at the air cylinder valve. The air valve should always be turned off when not in use. An air drain valve is provided on the bottom of the filter and should be opened briefly and periodically to expel any moisture which may be captured in the filter. This should be done with the air system turned on. Use and care of the air system should follow departmental procedures and guidelines.

Located at the pedestal and platform are low air warning devices. They will sound an audible alarm when breathing air pressure is low. Personnel using the air should move to a nonhazardous area when the alarm sounds.

There is a silence button located on the platform control station and one located on the pedestal control station that will temporarily silence the platform alarm or the pedestal alarm. The alarm will automatically sound after two minutes, when silenced, if the air is still low.



1.19 Climbing Aerial or Using as an Escapeway

Extend or retract the aerial slightly until the RUNG ALIGNMENT LIGHT is on, indicating that the rungs of the ladder are aligned where one section overlaps another, making it easier to climb.

When climbing the tower or when escape procedure is in progress, the UPPER POWER switches in the platform and at the turntable pedestal should be turned off, so as not to accidentally move the tower in any way.

1.20 Rappelling

Sutphen Corporation does not approve rappelling from any portion of the aerial device as we cannot control the impact loading implied upon the aerial by the sudden decelerations associated with this procedure. The lifting eyes, when provided, are tie-off points for static loads associated with rescue operations.

1.21 Loading Hose

When loading hose in the main hose bed, it is helpful to raise the boom slightly.



CAUTION

Survey the area for overhead obstructions before raising the aerial.



CAUTION

Never rotate the aerial off to the side of the vehicle during this operation unless the outriggers are fully deployed.

Before raising the aerial, set the front and rear jacks properly to provide stability to the truck and to transfer the force of bedding the boom to the ground. To raise the boom out of the bed, use the interlock override button on the top of the pedestal and hydraulic compartment.

1.22 Aerial Take Down Procedures

Stowing the Aerial Device

1. Retract aerial fully by moving the appropriate lever in the direction indicated.



CAUTION

Before retracting the aerial, make sure that the nozzle and waterway drain are open to avoid compressing any water in the waterway. Allow waterway time to drain before retracting the tower. Failure to do so can result in serious damage to the waterway. Point both nozzles down to minimize the chance of being hit during travel.

2. Rotate the aerial to the left or right until it is properly aligned and the alignment light is lighted. The aerial is now in position to lower into the support cradle.
3. Lower the aerial until it reaches the cradle, making sure the alignment light is still on before actually entering the cradle. The throttle must be at idle when actually entering the cradle area.



WARNING

Bedding the aerial at any speed other than idle may damage the vehicle.

4. After the tower is lowered into the cradle, continue to hold the control lever in the lower position a few seconds, then release the lever to permit a pilot check valve in the hydraulic circuit to trip and lock at its preset pressure. This locks the tower in the cradle for travel. This procedure works the same at either the controls at the pedestal or in the platform.
5. Turn control power switches off and exit the platform or pedestal.
6. Remove the wheel chocks.

NOTE: Always remove the wheel chocks before releasing the stabilizers. Failure to do so could result in wedging the chocks tightly against the tires making them extremely difficult to remove.

7. Remove safety pins in outriggers and replace them in their holders.



NOTE: The interlock system will not allow the oil to be transferred to the jack system until both of the safety pins have been removed and the UPPER POWER/HYD. TRANSFER switch is off.

8. Retract the stabilizers-
 - A. Move to the ground jack controls compartment.
 - B. Turn off UPPER POWER/HYD. TRANSFER switch for transfer.
 - C. Retract the stabilizers by reversing the setup procedure, moving from right to left.
 - D. Replace the auxiliary outrigger pads in their holders before retracting the outriggers.
 - E. Push the operator's step in and lock in place with the locking bar.
9. Enter the cab and disengage the fire pump if used.
 - A. Shift transmission to Neutral (N).
 - B. Wait until speedometer registers 0 miles per hour.
 - C. Move pump shift lever from PUMP position to ROAD position.
10. Disengage the PTO switch from IN to OUT position. Observe that the red pilot light goes out.
11. Release parking brake.
12. Place transmission in appropriate gear [Drive (D) 1-4 or Reverse (R)].



CAUTION

Before driving away, the operator should make a quick inspection trip around the truck to make sure all tools and appliances have been removed and stowed, compartment doors are closed, and that the vehicle is unobstructed.

Operator must also check the five warning lights on the in-cab dashboard marked UPPER POWER, JACKS OUT, JACKS DOWN, CAB DOOR OPEN, and COMPARTMENT DOOR OPEN making sure they are not lighted.




WARNING

All personnel must be seated and seat belts fastened before unit is moved.



WARNING


Never operate the truck in reverse unless a guide or spotter has been placed at the rear of the truck, giving clear signals to the operator. If the guide or spotter disappears from view, the movement must be stopped until the guide or spotter reappears.




REVISED 11/25/03

| | | | |
|---|-------------------|---------------|---------------------|
| SUTPHEN CORPORATION 7000 COLUMBUS-HAYSTACK ROAD JACKSON, OHIO 43022 | | INTEREST | |
| BY: J. HALLMAN | SUTPHEN 252" W.B. | DATE: 8/21/98 | FIG. NO: 252TURN-95 |
| NO. 8/21/98 | MODEL 95 PLATFORM | DATE: | |
| NONE | | | |


Operator Manual






| | |
|----------------------------|---------------|
| REVISED & REDRAWN 4/13/88 | |
| SUTPHEN CORPORATION | |
| 7900 COLLINGSWOOD AVENUE | |
| MILFORD, OHIO 45130 | |
| BY: J. HALLMAN | DATE: 4/13/88 |
| CHK: SUTPHEN | DATE: 4/13/88 |
| APP: NONE | DATE: NONE |
| PROJECT: SUTPHEN 252" W.B. | NO. 252TUR |
| DESCRIPTION: 100' PLATFORM | |

Operator Manual





Chapter 2 Maintenance Manual

| | | |
|-----|--|------|
| 2.1 | Aerial Maintenance | 2-3 |
| | <i>Outrigger Beams</i> | 2-3 |
| | <i>Main Lift Cylinders</i> | 2-3 |
| | <i>Pivot Shaft Bearings</i> | 2-3 |
| | <i>Turntable Bearing</i> | 2-3 |
| | <i>Fairfield Drive</i> | 2-4 |
| | <i>Aerial Extension/Retraction Cylinders</i> | 2-5 |
| 2.2 | Cable Adjustment | 2-6 |
| | <i>Cable Lubrication</i> | 2-17 |
| | <i>Sheaves and Cables</i> | 2-17 |
| |  <i>Lacings</i> | 2-18 |
| | <i>Slide Block</i> | 2-19 |
| | Lubrication | 2-19 |
| | Description | 2-19 |
| | Daily Preventative Maintenance (PM) | 2-20 |
| | Before Beginning | 2-20 |
| | Standard Operating Procedure | 2-21 |
| | Periodic Preventative Maintenance (PM) | 2-23 |
| | <i>Cable Track</i> | 2-24 |
| | Maintenance | 2-24 |
| | <i>Waterway and Seals</i> | 2-26 |
| | <i>Hydraulic Oil Tank</i> | 2-27 |



Maintenance Manual

| | | |
|-----|--|------|
| | <i>Hydraulic Oil Tank Fill Procedure</i> | 2-28 |
| | <i>SPI 95 Fitted with</i> | |
| | <i>KFS 4573 Hydraulic Reservoir</i> | 2-29 |
| | <i>Fuel Tank</i> | 2-31 |
| 2.3 | Maintenance of Structure | 2-31 |
| | <i>Aluminum Tower Structure</i> | 2-31 |
| 2.4 | Sutphen-Recommended Torque Schedule | |
| | for Various Fasteners | 2-32 |
| 2.5 | Daily/Weekly Walk-Around Check for Mobile Fire Apparatus | 2-35 |
| 2.6 | Draining & Winterizing Trucks | 2-39 |



2.1 Aerial Maintenance

Outrigger Beams

These are the beams on which the main outrigger jack cylinders are attached. They slide in and out to position the jacks and should be lubricated slightly on the bottom side with a thin film of multipurpose grease as required. The large and small tubes are to be lubricated by hand.

Main Lift Cylinders

The main lift cylinders have been provided with composite bearings in both ends of the cylinder which require no routine maintenance.

NOTE: There are two Allen screws used as locking pins to secure the rod eye to the ram cylinder. These Allen screws should be checked and re-tightened at this time.

Pivot Shaft Bearings

Located on the top of the upper assembly side plates are two pivot shaft bearings, one on each side, which rotate on the pivot shaft. The pivot shaft is attached permanently to the turntable side plates on the outside of the side plates. There are grease fittings installed on the pivot shaft bearings. These bearings should be lubricated with a good grade multipurpose grease every 10 hours of operation, or annually, whichever occurs first.

Turntable Bearing

This bearing and drive gear assembly is located directly under the turntable. The entire turntable and tower assembly rotates on this bearing. This bearing is pre-lubricated at the factory with a multipurpose grease. Grease fittings are provided on the outside of the bearing accessible through the outrigger openings, one each side below the turntable. Lubrication should be done two times per year. Use multi-purpose grease.

NOTE: At this time, we recommend that all the bolts attaching the turntable to the bearing and all the bolts attaching the bearing to the main frame should be checked for tightness. They should be checked at 175 ft/lb of torque.

**DANGER**

The person operating the turntable for bolt alignment must make sure that all persons and tools are free and clear before rotating.

The drive pinion gear and the turntable bearing gear have been lubricated with a special permanent elastic lubricant designed to last the life of the unit.

Fairfield Drive

The turntable is equipped with a rotating mechanism consisting of two hydraulically powered, planetary gear boxes (Fairfield Drives) that provide rotation for the boom. The power operated turntable provides continuous rotating of the aerial structure clockwise or counter clockwise, thus enabling the boom to be positioned in any segment through 360 degrees. The rotating mechanism also provides sufficient power to rotate the aerial sections in any direction at any angle, fully extended, while carrying the rated load capacity with the waterway in operation and discharging water at the tip of the aerial fly section.

A brake system is incorporated into the Fairfield drives and is capable of holding the turntable in a stationary position regardless of the angle or extension of the aerial, while carrying the rated load capacity with the waterway in operation and discharging water at the tip of the aerial fly section.

In the event of a loss of engine power, emergency operation of the rotation system is possible through an auxiliary power unit that is capable of providing hydraulic power to safely rotate the aerial. It is necessary to release the parking brake when operating with the emergency auxiliary power unit and the manual handles at the Pedestal.




Aerial Extension/Retraction Cylinders


Located on each side of the first tower section is a cylinder which extends and retracts the tower assembly. There is only one point on the cylinder which requires lubrication; this being at the rod end eye. A grease fitting is provided on the rod eye of the cylinder and should be lubricated two times per year. Use multipurpose grease. At each end of the cylinder there are bolts attaching the cylinder pin to the tower. These bolts should be checked every three (3) months for tightness.

▼ **Maintenance Manual**


2.2 Cable Adjustment



1. Extend ladder all the way out.




**NOTE: Both sets of bottom cables - extends (A) will be tight/loaded.
Bucket and waterway (B) must be empty/not loaded.**



NOTE: Both sets of inside cables - retracts (C) will be loose/relaxed.

▼ **Maintenance Manual**



2. Retract ladder approximately 6 to 12 inches.

NOTE: Both sets of bottom cables - extends (D) will droop/relax.



3. Inspect all cables, pins, and sheaves for damage.



WARNING

Ladder is to be placed Out-of-Service if any damage is found and must be repaired with a new Re-Certification Inspection.

Items considered to be placed Out-of-Service:


Cables

- Any one strand broken
- Frayed
- Rusted
- Unraveling
- Pin damage
- Missing jam nut
- Any other damage


Sheaves

- Rubbing anything
- Bearing failure/damage
- Not rotating/seized
- Pin damage
- Any other damage

▼ **Maintenance Manual**




NOTE: Cable pins must have lock pin/cotter pins (F) installed/secure.



4. Locate the steel beams (G) that each set of cables run over top of.



5. Locate the steel beams (H) that each set of cables run over top of.




6. Adjust cable clearance (I) to be between resting slightly on each steel beam, to 1/4 inch off of each steel beam.

NOTE: If the assessment is borderline; do not adjust.


▼ **Maintenance Manual**




7. Follow the cable around the sheave to the adjustment nuts.



8. Follow the cable around the sheave to the adjustment nuts.



9. Loosen the outer jam nut (J) while holding the inner adjustment nut (K).



10. Adjust inner adjustment nut (K) and recheck for proper cable clearance.



WARNING


Failure to hold the square end of the threaded rod (L) when adjusting will cause cable damage.

▼ **Maintenance Manual**




11. Adjust inner nut and recheck for proper cable clearance (M).


NOTE: Cable clearance can be between resting slightly on each steel beam, to 1/4 inch off of each steel beam.



12. With finger tips, check left-side (N) and right-side (O) cable with finger tips to make sure tension feels about equal on both cables.



13. Retighten jam nut (J) while holding the inner adjustment nut (K).




14. Retract ladder all the way in.

NOTE: Make sure sections (P and Q) do not touch.


If sections touch, the cables require tightening/loosening as needed to pull that section outward.

▼ **Maintenance Manual**



CAUTION


For high hand rails, improper cable timing can cause potential trip hazard ladder rungs. Cables will need tightened/loosened as needed for better rung alignment.



This photo eye sensor (R) reflects light off the side of the ladder until aligned with the hole (S) of a ladder rung, which then turns on the rung alignment light. The rungs should now be aligned for climbing and should not be a trip hazard.



Cable Lubrication

Periodically wipe all cables (T and U) with a damp rag and apply thin film of Chain Mate or Vitalife 400 to 


- Clean
- Re-lubricate
- Check for snagging on any broken wire strand.

Sheaves

There are sheaves and cables which are part of the tower extension/retraction system from the second section on up. The sheaves are greaseless composite bearings that require no lubrication.

If you see a distinct, irremovable black ring around any of the sheaves, contact your local certified Sutphen service center because the sheave may need to be replaced.

Cables

When servicing the cables, the tower should be extended horizontally to maximum position, and the cables wiped free of any dirt and/or grime with a slightly moist naphtha cloth and then lubricated with a thin film of Chain Mate or Vitalife 400. 

Lacings

Located on the boom of the aerial, lacings are supports that can be connected to the long structural angles of the boom by bolts and/or huck bolts. 1/4" - 3/8" bolted connections on the lacings are to be torqued to 5 ft-lbs with a lock nut. For huck bolts connections- re-torquing is not required.

Any indication of huck bolts loosening or any bolt failure should be reported to Sutphen Corporation for evaluation and disposition.



DANGER

Stabilizers must be set before performing this operation.



DANGER

If any strand of the cable is fractured or damaged, immediately lower the aerial and retract slowly. Remove from service until repaired.




DANGER

Inspection holes in cable eye will allow cable to be seen. Cable should be in good condition.

Slide Block

Lubrication

| Bill of Materials | Required Tools |
|---|---|
|  <p>Sutphen recommends: ProOne EP-2 Grease For more information, see the email or website below: Email: info@pro-one.us www.pro1energy.com To purchase ProOne EP-2 Grease email below Email: Sales@GlobalGreenLubricants.com</p> | <p>Painters brush or foam brush Extended pole for the brush</p> |

Description

Slide Blocks are the composite parts attached to the ends of the tower at both the upper, lower and side positions on each section. They support each section of the tower, so no metal-to metal contact can occur.

The material is a UHMW polymer compound and is designed to withstand heavy loads. Lubrication is required in the path in which the slide blocks travel on each section. The slide block paths on the aerial have been coated with a gray ProOne Grease (see Bill of Materials above). It is available in convenient 400 gram cartridges.

Maintenance Manual

Daily Preventative Maintenance (PM)

It is important to review as part of preoperation the aerial slide pads and path on each section. Foreign material may become lodged between the ladder sections and the slide pads. This inevitably could cause damage to the tower. Sutphen recommends reviewing the slide pads and slide area daily. Make sure that the sliding area has a thin coating of grease along all of the slide path areas.

NOTE: Within the work instruction below, you will note key quality and safety points identified with either a "Q" or an "S". Pay special attention to these items in detail for safe and quality results.

Before Beginning



WARNING


Stabilizers must be set before performing this operation. Failure to set stabilizers before performing this procedure could result in severe injury or death.

In order to properly lubricate the tower, extend the tower to the side of the truck and lower the boom so you can reach all sides of the aerial device.









Standard Operating Procedure

| Step No. | Q/S | Process Step Description | Associated Picture and/or Key Details |
|----------|-------------------|--|---|
| 1 | <p>Q</p> <p>Q</p> | <p>Using a brush:</p> <p>Apply a liberal amount of grease in the area above and below where the vertical lacings come in contact with the long structural angles of the boom.</p> <p>Apply grease on the interior, exterior, and sides of the aerial.</p> <p>NOTE: In order to reach some of the areas within the boom, an extended pole might be needed.</p> |  |

Note: As the boom is extended and retracted, the grease will build up in the grease pockets of the slide blocks and distribute across the angle sections as shown.



Maintenance Manual

| | | | |
|----------|----------------------------|---|---|
| <p>2</p> | <p>S</p> | <p>Once all areas are properly lubricated, raise the ladder while it is fully extended to 70 degrees.</p> <p> CAUTION Be aware of all surroundings while lifting/ extending the boom assembly.</p> <p>Once the boom is raised, extend and retract the boom 5 to 6 times while at 70 degrees.</p> <p>This step will apply grease to the entire length of the aerial.</p> |  |
| <p>3</p> | <p>Q</p> <p>Q</p> <p>Q</p> | <p>Next, bring the aerial back to the position in which it was while originally applying grease, extended off to the side of the truck.</p> <p>Review all slide block paths to make sure the grease is applied evenly.</p> <p>A correctly greased ladder section should resemble the one shown to the right.</p> <p>If you find areas where grease is missing or the slide path appears dry, apply additional product to that area.</p> |   |



Periodic Preventative Maintenance (PM)

Periodically, the ladder will need to be steamed-cleaned or pressure-washed to remove the grease material and then new product applied. Depending on the aerial usage hours, operating conditions and age of the existing grease, and the amount of time between thorough cleanings, will vary. A clean film of grease is always the best application for the aerial, so if any area becomes contaminated with debris, metal shavings, etc., it is recommended that you again remove the existing product and apply new.

There are exceptions to this schedule that should be considered. Should the tower be operated at a fire and exposed to excessive dirt and grime, we recommend that the slide block travel paths be cleaned and the tower be coated. Do not overcoat. A medium film of ProOne Grease NLGI Grade 2 in the path of the slide block travel is adequate.

Do not clean your aerial using any cleaning agents or solvents that can cause chemical degradation to plastic slide blocks or other parts made from the same UHMW material.


Cleaning agents or solvents containing the following chemicals should not be used: chlorine, benzene, toluene or any compound with a Ph over 10 (i.e., sodium hydroxide).


Use of agents containing the above chemical will void your warranty due to the fact that it may cause surface cracking of the UHMW plastic material.

Cable Track


The cable track should be inspected, maintained and cleaned after each use.

Maintenance

- The cable track assembly used on aerial ladders consists of the cable track containing the cables in the boom for electrical controls and the supporting cable troughs. Both the cable track and the cable troughs must be cleaned on a regular basis to maintain proper functionality. Cleaning must be done at least annually, or sooner, if debris is found in the cable track or troughs.
- Inspect the cable track and troughs for debris after the aerial has been used on scene during fire fighting, or if it is suspected debris may have fallen into the ladder from trees or other objects while driving. Otherwise, it is recommended to inspect after 25  hours of operation.
- To clean the cable track assembly, the vehicle must be set up for aerial operation to facilitate cleaning. Refer to this operator and maintenance manual for the proper procedure for setting the jacks and operating the aerial.
- Once the jacks are set, position the ladder over one side with the ladder fully extended and the platform touching the ground.
- Check for debris and remove any if found.
- Do not use solvents or detergents of any kind to clean the cable track or troughs. Clean the cable track and troughs with water using a hose no larger than 1-inch diameter and do not use more than 100 psi.
- After cleaning the cable track and troughs with water, use compressed air to remove residual water and blow out any remaining debris or dust.



- The picture above shows a cable trough that has been properly cleaned. Lightly apply dry film spray.
- When finished cleaning, inspect the cable track for any damage or doors that may be loose or missing. Make sure all cable track doors are securely locked in place before retracting the ladder.



- The picture above shows the cable track with doors intact and properly locked in place.
- The ladder is now ready to be retracted, stowed, and returned to service.

Waterway and Seals

This is the telescopic tube device inside the tower that carries the water to the tower nozzle. It has seals which ride on the internal honed and hard-coated surface of the tubes. These seals are made with an impregnated lubricant and should be adequately self-lubricated and cleaned by the water that passes through the waterway. However, it will prolong the life of your waterway if it is wiped off periodically with a rag saturated with ATF / Dex Merc.

The outside of the tubes are provided with nylon bearing collar assemblies built in the mounting collar of each section. The outside of the tubes should be kept wiped free of dirt and grime to protect the bearings. Should the aerial be used under extremely dirty conditions, the waterway should be wiped off before retracting to keep dirt from entering the bearings. The ladder is best accessed with it fully extended and lowered over one of the outriggers.

Consistent cleaning of the tower travel paths is the best and most inexpensive maintenance you can perform to keep the tower in perfect operation condition.



DANGER

Never extend or move the tower in any way while persons are on the tower.

NOTE: The hydraulic oil tank is located behind the outriggers control panel.

Hydraulic Oil Tank

Located behind the outrigger, this tank has a capacity of 65 gallons. It has a special filter screen installed. The oil level can be seen in the sight glass on the side of the tank. The hydraulic oil furnished in the tank is ATF Dex Merc.



CAUTION

When checking or adding oil, make sure all hydraulic systems are at rest (retracted). Failure to do so will result in overfilling the system.

HYDRAULIC OIL SPECIFICATIONS:

ANY OIL CHANGES OR ADDITIONS SHOULD BE DEX MERC,
FILTERED TO AT-LEAST ISO 22/18/13 CLEANLINESS LEVEL.

UN-FILTERED OIL MAY ACCELERATE WEAR AND DECREASE
PERFORMANCE OF SOME COMPONENTS.



Tag Dimensions: 3.0" height x 4.0" long

Hydraulic Oil Tank Fill Procedure

NOTE: Use only clean oil to fill reservoir

1. Locate the Hydraulic Tank Fill Port behind the outrigger.
2. Check the current oil level. Proceed only if it is below the full level. If it is at, or above the full mark, the system is full.

NOTE: you can locate the high psi filter under the cab





SPI 95 Fitted with KFS 4573 Hydraulic Reservoir

This Hydraulic reservoir is fitted with a MP Filtri Tank Top Filter and a dip stick.

This hydraulic reservoir is full with all cylinders in the stowed position 3-5 inches from the top of the tank.

Hydraulic fluid should be changed every **500 hours of operation or once a year**, whichever comes first. The hydraulic oil furnished in the tank is ATF Dex Merc.

The return filter is fitted with a by-pass indicator. Change this filter if the by-pass indicator is going into the red. This must be observed when the unit is in operation. With the unit fully set up at high idle, observe the by-pass indicator. When running at high idle, retract and lower at the same time. This is the highest flow rate the filter will see. Otherwise, change this filter after the first **50 hours of operation and 250 hours thereafter**.

Please replace with MP Filtri original equipment element # MF1801A06HB.

When checking the high-pressure filter, the hydraulic system must be in operation

with multiple functions being performed (for example: extend, lower, or retract

ladder). If the indicator on the filter housing is in the green zone, the filter is good.


If the indicator on the filter housing is in the red zone, replace the filter. When the

truck is put into service, replace the filter after the first 25 hours of operation.

After

that, replace the filter as needed according to the filter indicator on the housing.

Maintenance Manual





Fuel Tank

The fuel tank is located behind the rear axle. It has a capacity of 65 gallons. The filler for the tank is located on the left-rear fender panel. A nameplate marked Diesel Fuel Only is attached near the filler for proper identification. Use #2 diesel fuel under normal conditions.

2.3 Maintenance of Structure

Aluminum Tower Structure

The tower structure members are #6061-T6 aluminum alloy extrusion. This alloy is very resistant to corrosion and requires very little maintenance. Periodic washing with clear water only is recommended. Use mineral spirits for removal of tar, oil, and smoke film. If a brighter appearance is desired, use any quality automotive polish, a mag and aluminum wheel cleaner, or a Scotchbrite pad.

NOTE: Sutphen recommends that once a week the ladder should be raised to full elevation, full extension, then rotated completely 360 degrees in both directions.

2.4 Sutphen-Recommended Torque Schedule for Various Fasteners

See drawing for location of various fasteners.

Section A - Side plate pivot shaft bearings. Bolts used are ½” standard thread with Stover locking nuts. Torque to 70 to 80 ft/lb.

Section B - Pivot shaft end caps. Bolts used are 3/8” Grade 5 in tapped holes in pivot shaft with lockwashers. Torque to 25 to 30 ft/lb.

Section C - Waterway support brace between side plates of boom. Bolts used are 3/4” standard thread in tapped hole on end of brace assembly. Torque to 150 to 200 ft/lb.

Section D - Pin through lift cylinder rod eye each side with securing ear. Bolts used are ½” standard thread with Stover lock nuts. Torque to 40 to 50 ft/lb.

Section E - Fairfield Drive for rotation. Bolts used are 5/8” standard thread with torque washers and Stover lock nuts on Fairfield Drive, torque to 175 to 185 ft/lb. Crossplates, at rear of Fairfield Drive bolts, are ½” standard thread with lock washers and nuts. Torque to 75 to 85 ft/lb.

Section F - Turntable bolts, top and bottom. Top bolts secure the turntable to the bearing assembly. The bottom bolts secure the turntable bearing to the turntable main frame assembly. Bolts used are 5/8-11. Torque to 175 to 185 ft/lb.

Section G - Curved crossplate between boom side plates. Bolts used are 3/8” grade 8 standard thread with lockwashers and nuts. Torque to 25 to 30 ft/lb.

Section H - Angle crossplate at bottom of boom side plates. Bolts used are 3/8” grade 8 standard thread with lockwashers and nuts. Torque to 25 to 30 ft/lb.

Section I - Pin through base of lift cylinder each side with securing ear. Bolts used are ½” standard thread with Stover nuts. Torque to 40 to 50 ft/lb.



Section J - Turntable main frame assembly secured to chassis frame rails. Bolts used are 16 mm Grade 8 Huck bolts and do not require torquing.

Section K - Ground jack hydraulic cylinders attached to jack outrigger plates. Bolts used are 1" standard thread with Stover locking nuts. Torque to 550 to 600 ft/lb.

Section L - Pin through base of extend/retract cylinder each side with securing ear. Bolts used are 3/8" grade 8 standard thread with Stover locking nuts. Torque to 15 to 20 ft/lb.

Section M - Cross supports attached to boom assembly to support extend/retract cylinders on side of boom. Bolts used are 3/8" grade 8 standard thread with Stover lock nuts. Torque to 30 to 36 ft/lb. Section M also includes other brackets that hold sheaves and cable end brackets to each boom section. Bolts used are 3/8" standard thread with Stover locking nuts. Torque to 30 to 36 ft/lb.


Section N - Yoke side plates are attached to the fly section of the boom each side. Bolts used are 3/8" standard thread with Stover locking nuts. Torque to 25 to 30 ft/lb.


Section O - Pin through rod eye of extend/retract cylinder each side with securing ear. Bolts used are 3/8" standard thread with Stover locking nuts. Torque to 15 to 20 ft/lb.

Section P - Bolts that secure platform to yoke assembly. These are 3/4" standard thread special hardened bolts secured with Stover locking nuts. These do not require a full torque rate, as they are locked in place by the pivot bearing attached to the platform. Torque to 50 to 60 ft/lb.

Section Q - Bolts that secure aerial lacings on boom. 1/4" - 3/8" bolted connections on lacings are to be torqued to 5 ft/lb.

Maintenance Manual





| | |
|---|--|
|  SUTPHEN CORPORATION 1000 W. MAIN ST. WINDY HILL, N.J. 07093 | |
| Mr. T. STITES DATE: 12/18/98 TRUCK # 11- | Mr. REBE BOLT LOCATIONS MODEL 95 LOW RAIL AT-C-1703 |
| NONE | NONE |



**WALK-AROUND CHECKS
FOR MOBILE FIRE APPARATUS**

| | | |
|-----------------------|---------------------|-----------------------|
| Fire Department Name: | Date: | Special Instructions: |
| Truck Model: | HS #: | |
| Truck Number: | Station #: | |
| Start Mileage: | Start Engine Hours: | |
| End Mileage: | End Engine Hours: | |
| | | |

Legend: Rec Min. = Recommended Minimum Interval for Inspection

| OPERATIONS | Daily | Weekly | Monthly | 6 Months | Annual |
|---|--------------|---------------|----------------|-----------------|---------------|
| Engine – Tilt Cab – Make sure safety prop is engaged and there are no obstructions on the bumper or in the cab. | | | | | |
| 1. Check engine oil and transmission level. Check for leaks (see Manual). | Rec Min. | | | | |
| 2. Check engine coolant level – sight glass. Check for leaks. | Rec Min. | | | | |
| 3. Check for integrity of frame and suspension, as well as motor assembly and mount. Check for loose bolts. | | | Rec Min. | | |
| 4. Check power steering fluid level and look for leaks at fitting or hoses. Transynd  | Rec Min. | | | | |
| 5. Check belts for tightness and wear. | Rec Min. | | | | |
| 6. Check steering shafts. | | | Rec Min. | | |
| 7. Check for exhaust leaks. Check heat shields are in place. | | | Rec Min. | | |
| Outside | | | | | |
| 1. Check for fluid leaks under vehicle. | Rec Min. | | | | |
| 2. Check steering shafts and linkages. | | | Rec Min. | | |
| 3. Check wheels and lug nuts for tightness. | | | Rec Min. | | |
| 4. Check tire condition. – Tread Depth. (wear/damage) | Rec Min. | | | | |
| 5. Check tire air pressure. | Rec Min. | | | | |
| 6. Verify all warning label & placards are in place (see Manual). | | Rec Min. | | | |
| 7. Check driveline U-joints and slip joints. Lubricate if necessary. Check for tightness on all universal bolts. Visual check. | | | Rec Min. | | |
| Cab – lower cab | | | | | |
| 1. Check seats and seat belts (damage/warning system) and ensure working properly. | Rec Min. | | | | |
| 2. Start engine, check all gauges, switches, & controls. | Rec Min. | | | | |
| 3. Check windshield wipers & washer fluid level check | Rec Min. | | | | |
| 4. Check rear view mirrors adjustment and operation. R & L | Rec Min. | | | | |
| 5. Check horn, air horn, siren and backup alarm. | Rec Min. | | | | |
| 6. Check all gauges for correct reading after start. Fuel Level Check. | Rec Min. | | | | |
| 7. Check cab glass and mirrors. | Rec Min. | | | | |
| Body | | | | | |
| 1. Check steps and running boards. (damage/loose hardware) | Rec Min. | | | | |
| 2. Check body condition. (doors/latching) | Rec Min. | | | | |
| 3. Check grab handles. (hardware tight secure) | Rec Min. | | | | |
| Electric | | | | | |
| 1. Check battery voltage and charging system voltage, 13 +VDC. | Rec Min. | | | | |
| 2. Check all lights (ICC and warning); headlights. | Rec Min. | | | | |

| OPERATIONS | Daily | Weekly | Monthly | 6 Months | Annual |
|--|----------|----------|----------|----------|--------|
| 3. Check operation of battery charger and receptacle. | Rec Min. | | | | |
| Brakes | | | | | |
| 1. Check air system for proper air pressure. (see tech manual) | Rec Min. | | | | |
| 2. Check parking brake operation. | Rec Min. | | | | |
| 3. Check air compressor operations. Cut in _____ Cut out _____ | Rec Min. | | | | |
| 4. Check hoses or lines for rubbing. | | | Rec Min. | | |
| 5. Drain wet air tank to make sure air dryer is working properly | | | Rec Min. | | |
| Pump | | | | | |
| 1. Operate pump, check pump panel engine gauges. | Rec Min. | | | | |
| 2. Check pump for pressure operation. | Rec Min. | | | | |
| 3. Check discharge relief or pressure governor operation. | Rec Min. | | | | |
| 4. Check all pump drain valves. | | Rec Min. | | | |
| 5. Check all discharge and intake valve operation. | | Rec Min. | | | |
| 6. Check pump and tank for water leaks. | | Rec Min. | | | |
| 7. Check all valve bleeder/drain operation. | | Rec Min. | | | |
| 8. Check primer pump operation. | | | Rec Min. | | |
| 9. Check system vacuum hold. | | | Rec Min. | | |
| 10. Check water tank level indicator. | Rec Min. | | | | |
| 11. Check primer oil level (if applicable). | | Rec Min. | | | |
| 12. Check transfer valve operation (if equipped). | | | Rec Min. | | |
| 13. Check booster reel operation (if equipped). | | Rec Min. | | | |
| 14. Check all pump pressure gauge operation. | Rec Min. | | | | |
| 15. Check all cooler valves. | | | Rec Min. | | |
| 16. Check for oil leaks in pump area. | Rec Min. | | | | |
| 17. Check oil level of pump transmission. | | | Rec Min. | | |
| 18. Check hour meter operation (If equipped) | Rec Min. | | | | |
| 19. Check operation of valve linkage. | Rec Min. | | | | |
| 20. Check ball valves for leaks. | | Rec Min. | | | |
| 21. Check drain valves. | | Rec Min. | | | |
| Generator | | | | | |
| 1. Operations – Hydraulic, Gas, or Diesel | Rec Min. | | | | |
| 2. Fluid levels | Rec Min. | | | | |
| 3. Breakers, Receptacles, lighting for operations | | Rec Min. | | | |
| 4. Voltage Reading, 240V AC | | Rec Min. | | | |
| Amp Reading | | Rec Min. | | | |
| HTZ Reading, 60HTZ | | Rec Min. | | | |
| Aerial Device | | | | | |
| 1. Visually inspect aerial structure, slide blocks, cables, sheaves, lacing bolts/ huck bolts and any moving assembly.  | | Rec Min. | | | |
| a. Sheaves – look for signs of wear | | Rec Min. | | | |
| b. Slide blocks – all in place (no visible signs of excess wear or damage) | | Rec Min. | | | |
| 2. Check aerial operation – all controls, bucket & pedestal. | | Rec Min. | | | |
| 3. Elevation cylinder, check for leaks & wiper seal (check RAM for pits and/or damage). | | Rec Min. | | | |
| 4. Extension cylinder, check for leaks & wiper seal (check RAM for pits and/or damage). | | Rec Min. | | | |
| 5. Lines & hoses – check for leaks and cuts. | | Rec Min. | | | |
| 6. Check aerial hour meter operation and record hours. | | Rec Min. | | | |

| OPERATIONS | Daily | Weekly | Monthly | 6 Months | Annual |
|--|-------|----------|----------|----------|--------|
| 7. Check breathing air system. | | Rec Min. | | | |
| 8. Cable adjustment not too tight and not too loose check all cables and sections. Review tolerance. (See directions in manual) | | | Rec Min. | | |
| 9. Observe operation of cable track system check for debris and/or damage. | | Rec Min. | | | |
| Waterway | | | | | |
| 1. Check waterway system operation, alignment, and check for damage. | | Rec Min. | | | |
| Hydraulic System | | | | | |
| 1. Check aerial hydraulic fluid level. DEX/MERC  | | Rec Min. | | | |
| 2. Check high pressure filter under load to ensure  is still in the green and not in bypass as well as return the filter. | | Rec Min. | | | |
| 3. Turn on auxiliary hydraulic power pump – check operation. | | Rec Min. | | | |
| Turntable | | | | | |
| 1. Operate aerial hydraulics + PTO operation (check for leaks or damaged hoses). Verify Indicator Light is functional. | | Rec Min. | | | |
| 2. Rotation | | Rec Min. | | | |
| 3. Rotation hydraulic swivel, check for leaks | | Rec Min. | | | |
| 4. Lines and hoses (for leaks & cuts) | | Rec Min. | | | |
| 5. Pivot pin bolts tight on boom to turn table pivot bearing plate (Heal Pin). | | | Rec Min. | | |
| 6. Check manual overrides. | | | Rec Min. | | |
| 7. Check cradle alignment light and mounting. | | Rec Min. | | | |
| 8. Check pinion and rotation bearing (Winsmith/rotation drives). | | | Rec Min. | | |
| Turntable Components or Hydraulic Compartment | | | | | |
| 1. Safety signs | | | Rec Min. | | |
| 2. Communication system or intercom | | Rec Min. | | | |
| 3. Interlock systems - operational | | Rec Min. | | | |
| 4. High-speed button operational | | Rec Min. | | | |
| Platform/Bucket | | | | | |
| 1. Leveling cylinders, leaks and wiper seal | | Rec Min. | | | |
| 2. Lines and hoses, cuts & leaks | | Rec Min. | | | |
| 3. Check operation of high speed. | | Rec Min. | | | |
| 4. Check operation of intercom system | | Rec Min. | | | |
| Platform/Bucket (continued) | | | | | |
| 5. Check breathing air system in platform - check for leaks and hose condition | | Rec Min. | | | |
| 6. Inspect monitors/turret for operation | | Rec Min. | | | |
| 7. Verify cab avoidance system is operational | | Rec Min. | | | |
| 8. Verify bucket leveling system is operational | | Rec Min. | | | |
| 9. Verify all accessories are secure in the platform | | Rec Min. | | | |
| Structural Fasteners - See Manual for Reference | | | | | |
| 1. Turntable mounting bolts - visual check for tightness | | | | Rec Min. | |
| 2. Chassis Suspension system bolts – visual check for tightness | | | | Rec Min. | |
| Stabilizers | | | | | |
| 1. Check aerial outrigger operation | | Rec Min. | | | |
| 2. Check aerial jack & rotation interlocks for operation | | Rec Min. | | | |
| 3. Indicator lights working | | Rec Min. | | | |
| 4. Jack pads in proper location & serviceable | | Rec Min. | | | |
| 5. Mounting bolts – visual check for tightness | | Rec Min. | | | |
| 6. Verify safety lock pins operation in aerial jacks and in location | | Rec Min. | | | |

| OPERATIONS | Daily | Weekly | Monthly | 6 Months | Annual |
|---|-------|----------|---------|----------|--------|
| 7. Cylinders – check for leaks & wiper seals | | Rec Min. | | | |
| 8. Control valve – smooth operation | | Rec Min. | | | |
| 9. Lines & hoses – check for leaks and cuts | | Rec Min. | | | |
| 10. Diverter valve – check for leaks | | Rec Min. | | | |
| Lubrication | | | | | |
| Grease Parts and Assemble as Required per the Trucks Maintenance Manual: | | | | | |
| 1. Sheaves - Min. Wkly or more if hours of operation dictate | | Rec Min. | | | |
| 2. Cables, wipe down with damp cloth, apply thin film of Chain Mate or Vitalife 400 | | Rec Min. | | | |
| 3. ProOne NLGI Grade 2 on boom section, review and add where needed per manual | | Rec Min. | | | |
| 4. Rotation gear and bearing | | | | Rec Min. | |
| 5. Rotation gear reduction box | | | | Rec Min. | |
| 6. Extension cylinder pins, grease pivot | | | | Rec Min. | |
| 7. Stabilizer extension cylinder pins | | | | Rec Min. | |
| 8. Aerial waterway pipe sections, wipe with DEX/MERC | | Rec Min. | | | |
| 9. Grease turret guns | | Rec Min. | | | |
| | | | | | |
| Indicators | | | | | |
| 1. Validate rung alignment operation; pedestal and bucket | | Rec Min. | | | |
| 2. PTO engaged in cab | | Rec Min. | | | |
| 3. Aerial alignment light for cradle bedding | | Rec Min. | | | |
| 4. Elevation/inclometer in bucket | | Rec Min. | | | |
| 5. Inclometer in turntable area for truck level. | | Rec Min. | | | |
| Comments: | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |



FAMILY OWNED
SINCE 1890

Draining & Winterizing Trucks

It is critical, especially during the cold months, to exercise caution when it comes to leaving trucks outside, transporting trucks, or accepting trucks into our possession. Anyone who gets behind the wheel of a truck is responsible for ensuring the truck is properly drained and stored.

Sutphen Guidelines for Draining and Winterizing Trucks

1. Communicate to all that water and foam tanks must be emptied prior to dropping any truck off to Sutphen for service.
2. Drain all trucks left outside completely, including water tanks, pumps, gauges and valves.
3. Ensure all valves (outboard and inline) are open 50% to drain trapped water.
 - Use caution if valve appears to be frozen in place; do not force a valve open or closed. Trucks may need warmed-up prior to operating frozen valves.
4. Run "RV antifreeze" through the foam pump and systems immediately after foam testing (approx. 3 gal.) from October through April.
5. Any truck being "Road Tested" needs to have all valves and drains open 50% to drain any trapped water. After road testing, the tank fill needs to be opened 100% to allow draining back into the pump. Ensure tank fill is turned back to 50% open after tank has fully drained back into the pump.

Please ensure everyone is fully aware of the expectations and follows the same guidelines. Thank you for your cooperation and dedication to avoiding costly repairs.



Chapter 3 Warranty

| | <u>Page</u> |
|--|-------------|
| Aerial Platform or Aerial Ladder Structural and Corrosion Warranty Thirty (30) Years..... | 3-3 |
| Aerial Platform and Aerial Ladder Mechanical Warranty Two (2) Years | 3-4 |



AERIAL PLATFORM OR AERIAL LADDER STRUCTURAL & CORROSION WARRANTY THIRTY (30) YEARS

SUTPHEN CORPORATION (Sutphen) warrants the original user/purchaser that a new aerial platform or aerial ladder is, and will remain, free of corrosion perforation and structural defects, provided the aerial platform is used in a normal and reasonable manner. An aerial platform or aerial ladder is defined as the mechanically operated telescopic boom constructed of high-strength structural aluminum mounted on the fire truck. Excluded are all hardware, mechanical or electrical items, bucket, yoke and all normal wear items. Truck must be third party tested yearly. The Sutphen hourly maintenance schedule must be sent in to Sutphen for documentation that this work was performed per hourly schedule. This Structural Warranty shall supplement the Standard Vehicle Warranty.

Sutphen's obligation under this limited warranty is subject to the conditions precedent (1) that the claimed failure shall have first appeared during the warranty period; (2) that the original purchaser shall have notified Sutphen in writing of the claimed failure within thirty (30) days after the claimed failure shall have first appeared, and (3) that, unless Sutphen directs otherwise, the claimed failed item or items shall have been returned to Sutphen, or to Sutphen designee, promptly after the notification, with transportation charges prepaid. Sutphen reserves the right to thoroughly examine the vehicle or parts thereof, prior to conducting or approving any repair or replacement, to determine whether the claimed failure is covered by this warranty. Sutphen's obligation under this warranty is strictly limited to repair or replacement as the company may elect.

This limited warranty coverage shall be valid for a period of thirty (30) years from the delivery date to the original user/purchaser. Further, this warranty shall be void if the vehicle is involved in an accident, shows signs of abuse, or evidence of being operated in any improper manner.

This limited warranty covers only repair or replacement of any part of a Sutphen vehicle in which a defect in materials or workmanship appears within the limited warranty period. Examples of items not covered include, but are not limited to:

- A. ---Major components or trade accessories such as purchased chassis, engines, signaling devices, batteries, generators, tires, or transmissions that have a separate warranty by the original manufacturer, or to equipment used in fire fighting.
- B. ---Unauthorized alteration or modification to the vehicle, including the body, chassis or components, after completion of the vehicle assembly by Sutphen and any problems that occur as a result of such alterations or modifications.
- C. ---Damage caused by collision, fire, theft, freezing, vandalism, riot, explosion, acts of God, war or objects striking the vehicle or any damage covered by owner insurance.
- D. ---Damage caused by misuse or improper operation of the vehicle such as driving over curbs, overloading, racing or off-road use.
- E. ---Damage caused by failure to follow the requirements of the maintenance schedule, failure to maintain proper fluid and lubricant levels and failure to follow operating instructions.
- F. ---Towing charges and storage expenses.
- G. ---Incidental expenses such as loss of vehicle use, inconvenience, loss of time, vehicle rental, lodging or travel costs, vacation pay, etc.
- H. ---Hydraulic pressures are not set to the correct PSI
- I. ---Damage caused from exposure to road de-icing compounds or use in an acidic environment.
- J. ---Hydraulic failures caused by incorrect or contaminated oil.
- K. ---Hydraulic cylinder seal after one (1) year of service.

If proper maintenance has not been performed and documented on Sutphen Aerial Platform or Aerial Ladder Inspection forms and the forms sent to Sutphen at the time of check, all coverage is void.

This warranty terminates upon transfer of possession or ownership of the vehicle from the original purchaser.

THIS WARRANTY IS PROVIDED IN EXCLUSION OF ANY AND ALL OTHER REPRESENTATIONS, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS, AND SUITABILITY FOR BUYER'S INTENDED USE. NO PERSON IS AUTHORIZED TO MAKE ANY REPRESENTATIONS OR WARRANTIES ON BEHALF OF SUTPHEN CORPORATION OTHER THAN SET FORTH HEREIN. ANY MODIFICATION TO THIS WARRANTY MUST BE IN WRITING AND APPROVED BY THE PRESIDENT OF SUTPHEN CORPORATION. THE PROVISIONS OF THIS LIMITED WARRANTY SHALL CONSTITUTE THE SOLE AND EXCLUSIVE REMEDIES OF A SUTPHEN VEHICLE PURCHASER.

For more information contact:
Sutphen Corporation / Warranty Admin.
PO Box 1845 • Springfield, OH 45501
Phone (937) 969-8851 • Toll Free (866) 287-5549



AERIAL PLATFORM AND AERIAL LADDER MECHANICAL WARRANTY TWO (2) YEARS

SUTPHEN CORPORATION (Sutphen) warrants the original user/purchaser that the mechanical components of a new aerial platform or aerial ladder is, and will remain, free of corrosion perforation, structural defects or failure provided that the components are used in a normal and reasonable manner. Mechanical components are defined as the hardware and mechanical items used on an aerial device. This Mechanical Warranty shall supplement the Standard Vehicle Warranty.

Sutphen's obligation under this limited warranty is subject to the conditions precedent (1) that the claimed failure shall have first appeared during the warranty period; (2) that the original purchaser shall have notified Sutphen in writing of the claimed failure within thirty (30) days after the claimed failure shall have first appeared, and (3) that, unless Sutphen directs otherwise, the claimed failed item or items shall have been returned to Sutphen, or to Sutphen designee, promptly after the notification, with transportation charges prepaid. Sutphen reserves the right to thoroughly examine the vehicle or parts thereof, prior to conducting or approving any repair or replacement, to determine whether the claimed failure is covered by this warranty. Sutphen's obligation under this warranty is strictly limited to repair or replacement as the company may elect.

This limited warranty coverage shall be valid for a period of two (2) years from the delivery date to the original user/purchaser. Further, this warranty shall be void if the vehicle is involved in an accident, shows signs of abuse, or evidence of being operated in an improper manner.

This limited warranty covers only repair or replacement of any part of a Sutphen vehicle in which a defect in materials or workmanship appears within the limited warranty period. Examples of items not covered include, but are not limited to:

- A. ---Major components or trade accessories that have a separate warranty by the original manufacturer, or equipment used in fire fighting.
- B. ---Unauthorized alteration or modification to the vehicle, including the aerial, body, chassis or components, after completion of the vehicle assembly by Sutphen and any problems that occur as a result of such alterations or modifications.
- C. ---Damage caused by collision, fire, theft, freezing, vandalism, riot, explosion, acts of God, war or objects striking the vehicle or any damage covered by owner insurance.
- D. ---Damage caused by misuse or improper operation of the vehicle such as driving over curbs, overloading, racing or off-road use.
- E. ---Damage caused by failure to follow the requirements of the maintenance schedule, failure to maintain proper fluid and lubricant levels and failure to follow operating instructions.
- F. ---Normal maintenance items such as lubrication, cables, shives, pivot bearings, pivot shafts, etc.
- G. ---Towing charges and storage expenses.
- H. ---Incidental expenses such as loss of vehicle use, inconvenience, loss of time, vehicle rental, lodging or travel costs, vacation pay, etc.
- I. ---Damage to discharge and compound gauges from freezing.
- J. ---Leaking seals on discharge and suction valves.
- K. ---Damage caused from exposure to road de-icing compounds or use in an acidic environment.
- L. ---Hydraulic failures caused by incorrect or contaminated oil.
- M. ---Hydraulic pressure caused by incorrect PSI settings.
- N. ---Hydraulic cylinder seal after one (1) year service.
- O. ---Electric reels, air reels, electric controls and components.

If proper maintenance has not been performed and documented on Sutphen Aerial Inspection forms and sent to Sutphen at time of check, all coverage is void.

This warranty terminates upon transfer of possession or ownership of the vehicle from the original purchaser.

THIS WARRANTY IS PROVIDED IN EXCLUSION OF ANY AND ALL OTHER REPRESENTATIONS, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS, AND SUITABILITY FOR BUYER'S INTENDED USE. NO PERSON IS AUTHORIZED TO MAKE ANY REPRESENTATIONS OR WARRANTIES ON BEHALF OF SUTPHEN CORPORATION OTHER THAN SET FORTH HEREIN. ANY MODIFICATION TO THIS WARRANTY MUST BE IN WRITING AND APPROVED BY THE PRESIDENT OF SUTPHEN CORPORATION. THE PROVISIONS OF THIS LIMITED WARRANTY SHALL CONSTITUTE THE SOLE AND EXCLUSIVE REMEDIES OF A SUTPHEN VEHICLE PURCHASER.

For more information contact:
Sutphen Corporation / Warranty Admin.
PO Box 1845 • Springfield, OH 45501
Phone (937) 969-8851 • Toll Free (866) 287-5549